



LASER CLEAN HEATING SYSTEM/VENTED HEATER INSTALLATION AND OPERATION INSTRUCTIONS

LASER CLEAN VENTED

MODEL **Laser 56**
(Type F & G)



IMPORTANT

READ AND UNDERSTAND INSTRUCTIONS BEFORE INSTALLING OR USING HEATER.
RETAIN INSTRUCTIONS FOR FUTURE REFERENCE. CHECK AND LOCAL CODES FOR PERMITTED USE.

CONTENTS

SECTION A:	SECTION G:
Specifications 2	Troubleshooting 14
Safety Features 3	SECTION H:
SECTION B:	Long Term Storage 16
Safety Tips for Operation 4	SECTION I:
SECTION C:	Installation:
Fuel Guide 5	Tools Needed for Installation 17
SECTION D:	Standard Installation Parts 17
Operating Controls and Part Names 6	Accessory Parts 19
SECTION E:	Safety Tips for Installation 22
Operation	Installation of Heater and Flue Pipe 23
Before Ignition 9	Permanent Wiring Installation 30
Operation 9	SECTION J:
Turning Heater Off 12	Fueling 31
SECTION F:	
Routine Maintenance 12	

SECTION A: SPECIFICATIONS

Model:	Laser 56
Heater Efficiency:	93% (1)
Heat Rating:	High — 22,000 BTU/h Med. — 15,000 BTU/h Low — 8,000 BTU/h
Fuel Consumption:	High — 0.165 gal/h Med. — 0.113 gal/h Low — 0.060 gal/h
Fuel System:	External tank (2)
Fuel Type:	Water Clear No. 1-K Kerosene Only
Dimensions (W x H x D): (Includes drip tray)	24-3/8" x 26-3/4" x 16"
Weight:	60 lbs. Empty
Vent Pipe Hole:	3-1/8" — 3-1/2" diameter
Maximum Length of Vent Pipe System:	10 ft., 3 bends or less
Electrical Rating:	120 Volts AC, 60Hz Preheat — 275W Burning — 60W
Typical Room Size(3):	920 square feet (0°F) 1100 square feet (20°F)

(1) Heat and vaporized water are produced by the combustion process of this kerosene heater. This rating does not take into account heat loss due to condensation of water vapor.

(2) External tank to be purchased from local suppliers.


(3) 0°F Heat Load = 24 BTU/ft²/hr

20°F Heat Load = 20 BTU/ft²/hr

Room size for which this heater is suitable will vary depending on outside temperature, house insulation, window size, and other factors.

SAFETY FEATURES

Your Laser 56 is equipped with the following safety features. Please familiarize yourself with these features. When your heater is extinguished due to a safety mechanism, be sure to identify and correct the problem.



1. Flame Sensor

Heater will automatically stop all operations if ignition fails or if flame fails during combustion, in order to prevent fuel overflow. Error code will be displayed on the digital indicator.

2. Fuel Strainer

Special strainer catches any dirt or impurities present in the fuel before it is sent to the burner.

3. Overheat Protector

Automatically stops all operations if heater cabinet reaches abnormally high temperatures due to motor malfunction or abnormal combustion, in order to prevent fire.

4. Power Failure Recovery System

If power fails during heater operation, heater will turn off. When power resumes, heater will automatically reignite to maintain the selected room temperature.

5. Fully Vented System

Flue pipe system provides outside air for combustion and vents all combustion products to the outdoors.


6. Fusible Link Valve

If a household fire should occur, bringing the fuel line or heater to extremely high temperatures, the fusible link valve will stop the fuel supply to the burner. This will prevent the fuel supply from the external tank continuing to flow into the house.


SECTION B: SAFETY TIPS FOR OPERATION

CAUTION: Heater and vent pipe system must be properly installed before operation. Please follow instructions under "Installation", Section I.

1. Never use any fuel other than water-clear kerosene (ASTM No.1-K Kerosene). **NEVER USE GASOLINE.** Use of gasoline can lead to uncontrollable flames, resulting in destructive fire.




2. Due to high surface temperatures, keep heater away from children, furniture and clothing while in operation (See Page 23).



3. To prevent abnormal operation and prolong heater life, be sure to perform routine maintenance (See Pages 12—13).




4. Never store or transport kerosene in other than a metal or plastic container that is (1) acceptable for kerosene, (2) non-red in color, and (3) clearly marked, "KEROSENE". Never store kerosene in the living space.



5. **Operating Temperature Range**
Use heater within the range of temperatures indicated in the right figure.

Point A: Room temperature 0°F
Outside Temperature -20°F

Point B: Room temperature 60°F
Outside Temperature -45°F



SECTION C: FUEL GUIDE

The Toyostove Laser 56 is designed for use with water clear No. 1-K kerosene only. Use of low-quality kerosene will cause burner performance to drop, leading to abnormal combustion and reduced heater life.

Purchase only 1-K kerosene in non-red cans reserved exclusively for kerosene and marked accordingly with the word "KEROSENE". Always store your kerosene in a separate area from where you store gasoline for your power equipment to avoid accidental use of gasoline in your heater.

What to Buy . . .

- ALWAYS :** Crystal clear, colorless, high-quality KEROSENE, ASTM No. 1-K.
- ALWAYS :** Kerosene free of contaminants, water or cloudiness.
- NEVER :** Gasoline, alcohol, white gas, camp stove fuel or additives.
- NEVER :** Yellow or sour-smelling fuel.

How to Use It . . . (when optional removable fuel tank is used)

- ALWAYS :** Fill heater away from living quarters when heater is cool; use siphon.
- ALWAYS :** Watch fuel gauge to avoid overfilling heater.

How to Store It . . .





- ALWAYS :** Store in a clean container, non-red in color, clearly marked KEROSENE.
- ALWAYS :** Store away from direct sunlight, heat sources or extreme temperature changes.
- NEVER :** In a glass container, or one that has been used for other fuels.
- NEVER :** For longer than six months. Begin each heating season with fresh kerosene; discard at the end of season.
- NEVER :** In the living space.

Why It is Important . . .

Pure, clean kerosene is essential for safe and efficient heater operation. Poor quality or contaminated kerosene can cause:


- Excess tar deposits on burner and flue pipe
- Incomplete combustion
- Reduced heater life

Use of a highly volatile flammable fuel such as gasoline can produce uncontrollable flames, creating a severe fire hazard.



SECTION D: OPERATING CONTROLS AND PART NAMES


Before using heater, familiarize yourself with the following operating controls and part names.



- | | |
|--------------------------------|---|
| 1. ON/OFF switch: | Main switch turns heater on and off. When switched on, heater begins operation and combustion starts after preheat period. |
| 2. Auto switch: | The switch turns automatic operation modes on and off which have been programmed into timer. |
| 3. Temperature selectors: | "NORMAL" and "SET-BACK" temperature selectors allow user to select desired temperature during manual or automatic operation. |
| 4. Timer & clock set: | Timer and clock set modes can be set by pressing hour or minute buttons. |
| 5. Timer selector: | Clock, clock set, "SET-BACK" mode, start time set and end time set can be selected by this switch. |
| 6. Digital indicator: | Displays clock, set temperature, room temperature and error code. |
| 7. Burning mode lamp: | Indicates whether heater is operating at high, medium or low combustion. |
| 8. ON/OFF lamp: | Lights when heater is in operation and flashes when heater is in prepurge or postpurge. |
| 9. Auto lamp: | Lights when automatic operation is in use. |
| 10. Normal temperature lamp: | Lights when heater runs with manual or "NORMAL" mode of automatic operation. |
| 11. Set-back temperature lamp: | Lights when heater runs with "SET-BACK" mode of automatic operation. |
| 12. Circulating fan: | Three-speed motor supplies high-capacity warm air flow during high combustion for heating room up quickly, and low or medium-capacity warm air flow during low or medium combustion for maintaining comfortable room temperature. |
| 13. Room temperature sensor: | Constantly senses room temperature and supplies information to heater so that desired room temperature can be maintained. |
| 14. Power supply cord: | For use in 120V, AC electrical outlets. |
| 15. Plumb bob: | Allows user to check if heater is positioned evenly. |

INDICATOR LAMPS

ON/OFF lamp	Flashing	- Pre-heating, pre-purging and post-purging mode
	Lit	- Heater in operation
AUTO lamp	Flashing	- Power loss of more than 10 seconds
	Lit	- Heater in operation at auto mode
LOW lamp	Lit	- Heater in operation at low combustion
MED lamp	Flashing	- Pre-purging mode (without flame)
	Lit	- Heater in operation at medium combustion
HIGH lamp	Lit	- Heater in operation at high combustion
NORMAL lamp	Lit	- Heater in operation at normal mode
SET-BACK lamp	Lit	- Heater in operation at set-back mode



RE. #	PART #	DESCRIPTION	RE. #	PART #	DESCRIPTION	RE. #	PART #	DESCRIPTION
1	20478346	Front panel assembly	31	20478337	Blower motor assembly (Type F)	59	20478501	Standard flue pipe (=20479801)
2	20475804	Carrying handle	32	20478737	Blower motor assembly (Type G)	60	20474925	Oil catch
3	20450007	Plumb bob	33	20478347	Blower motor assembly with case (Type F)	61	20475535	Power supply cord
4	20474970	Adjustable leg	34	20478747	Blower motor assembly with case (Type G)	62	20475922	Removable fuel tank with hose
5	20475929	Drip tray	35	20475971	Blower motor exhaust fan	63	20475722	Removable fuel tank without hose
6	20475960	Top plate with tank lid	36	20475983	Blower motor intake fan	64	20475925	Fuel supply hose
7	20475965	Tank lid with pin	37	20475978	Rubber mat	65	20475924	Fuel tank cap
8	20475566	Tank lid pin	38	20478082	O-ring (φ110)	66	20475923	Fuel gauge
9	20478063	Right side panel with access door	39	20475977	O-ring (φ49)	67	20474113	Burner mat
10	20475570	Level valve access door with pin	40	20478534	Fuel sump	68	20474059	Holder A
11	20478064	Left side panel	41	20478319	Fuel pump	69	20478156	Screw 1S
12	20475072	Fan cover	42	20478041	Fuel pipe assembly	70	20474050	Screw C
13	20478044	Heat exchanger	43	20478550	Inlet strainer	71	20474039	Insulator A
14	20478366	Air damper (φ25)	44	20475551	Drain screw with O-ring	72	20474057	Flange nut
15	20478542	Burner assembly	45	20475552	Strainer gasket	73	20475553	Screw 1P
16	20478343	Burner ring	46	20478512	Main circuit board	74	20474055	Screw O
17	20478026	Fuel nozzle	47	20478378	Fuse A	75	20450120	Screw for igniter unit
18	20478383	Fuel nozzle gasket	48	20478379	Fuse B	76	20478090	Screw 1T
19	20475518	Igniter	49	20478317	Transformer	77	20478091	Screw 1U
20	20474080	Igniter gasket	50	20478306	High limit switch	78	20475554	Screw 1Q
21	20474921	Igniter guide gasket	51	20478376	Indicator lamp circuit	79	20474049	Screw R
22	20474920	Igniter cover	52	20478301	Knob for temp selector	80	20474272	Screw M
23	20475011	Primary flame rod	53	20477414	PCB Support	81	20474051	Screw D
24	20475094	Burner gasket	54	20478314	PCB Support (S)	82	20475874	Washer for blower motor
25	20475093	Heat chamber gasket	55	10005597	Fusible link valve	83	20478008	Heat element assembly
26	20474983	Outlet adapter	56	20475952	Leveler fuel pipe	84	20475082	Lower gasket
27	20478009	Heat chamber assembly	57	20478569	Circulation fan motor	85	20475081	Upper gasket
28	20475831	Mica window	58	20478373	Thermistor	86	20478595	Instruction Manual
29	20475881	Peep window gasket				87	20478599	Carton (Type F)
30	20474992	Joint packing				88	20478799	Carton (Type G)

SECTION E: OPERATION

BEFORE IGNITION


1. Open the Valve(s)

Open the valve(s) of the external fuel tank.

2. Start the Fuel Flow

If using heater for the first time, or after heater has been out of fuel, press the red reset button once for a period of one second in order to send fuel to the fuel sump.

Note: Make sure there is no fuel leakage from the fuel line or joints.
Also make sure fuel tank is not too high. See installation instructions.



3. Plug in the Heater

Plug heater into a 120V AC electrical outlet.

Note: Do not connect to an outlet shared with other appliances.

4. Set Clock

Important: Clock on the heater always must be set to current time.

A. Position timer selector to "CLOCK SET".


B. Press "HOUR" and "MINUTE" button of TIMER/CLOCK SET to correct time.

Important: Check for the AM or PM indicators, to insure the correct time.

Note: "HOUR" or "MINUTE" button will change the time every one (1) unit. Holding the button continuously will cause the time to change rapidly.

Note: In the event of a power failure over ten (10) seconds, all clock and timer settings are cancelled. Digital indicator will flash "PM 12:00" when heater is off, or "AUTO" lamp will flash when heater is on and in automatic operation, after power is restored. However, no indications when heater is in manual operation. At this point, you need to reset all time and set-back functions.

C. Position timer selector to "CLOCK/TEMP (NORMAL POSITION)" after clock setting is completed. Current time will be shown on digital indicator.



OPERATION

Operation of Laser Heater can be controlled manually by the user — "MANUAL" operation (NORMAL mode only) or run automatically by the programming — "AUTOMATIC" operation (NORMAL mode and SET-BACK mode).

MANUAL OPERATION

"MANUAL" operation means that the set-back will not be in use but in "NORMAL" mode.

Operation of the heater is under the direct control of the user ("AUTO" switch is off). Heat output will, however, be automatically adjusted in accordance with the room temperature registered by the temperature sensor.


1. Select Manual Operation

Press the "AUTO" switch to "OFF" position.

2. Turn Heater ON

- A. Push in ON/OFF switch to "ON" position. The current room temperature and the set temperature will be shown on the digital indicator. ON/OFF lamp will start to flash and then blower motor and ignition will start.


Note: Heater will not start when room temperature is higher than the desired temperature setting.




- B. Burning mode lamp "MED" will start to flash after approx. 3 - 9 minutes and ignition will take place. (*) After ignition, burning mode lamp "MED" will change from flashing to continuous. And, after 10 seconds, burning mode lamp will turn to "LOW" and heater will start "LOW" burning mode. Circulation fan will turn on after approx. 3 minutes.

Note: (*) Pre-heating depends on the room temperature.

Room temperature: below 34°F - 9 minutes
34°F - 61°F - 6 minutes
over 61°F - 3 minutes



- C. Heater will operate at "LOW" or "MED" burning mode for approx. 6 minutes after ignition, regardless of temperature control setting. Heater will not go into "HIGH" burning mode while the prepurging is in effect. After this period, output can be adjusted as desired by using the "NORMAL" temperature selector as directed in the following instructions.





3. Adjusting Room Temperature


- A. Slide "NORMAL" temperature selector to set the room temperature desired. The temperature control should be set at the position you find most comfortable.

Note: Desired temperature setting will be displayed on the digital indicator when you set the room temperature.

Note: The scale on temperature selector is just for your reference. The figures on the digital indicator and on the scale may not match exactly; This is normal.




- B. Burning mode will be regulated automatically in accordance with the room temperature registered by the room temperature sensor. Heater will be operated at "HIGH" burning mode until room temperature reaches the selected temperature level.
- C. When room temperature reaches the selected setting, heater will automatically shift to "MED" or "LOW" burning mode to maintain the desired temperature.
When the room temperature exceeds the selected setting by approx. 4°F, the heater will automatically shut off. As room temperature drops, the heater will automatically re-start to maintain the desired temperature.



AUTOMATIC OPERATION

"AUTOMATIC" operation is established by programming the time/temperature settings for specific time, "SET-BACK" mode operation will be programmed in a 24-hour period. It is designed for energy efficiency by using a lower temperature setting, generally at night.

Ex.



1. Set Start Time of "SET-BACK" Mode.

A. Slide the timer selector to "START SET-BACK".

B. Press "HOUR" and "MINUTE" button of TIMER/CLOCK SET to set desired start time.

Note: When setting "SET-BACK" time, the "MINUTE" button will advance time by ten (10) units.
(Ex. 10:00, 10:10, 10:20, etc.)

C. Start time of "SET-BACK" mode will be shown on digital indicator. (Ex. PM 10:00)

2. Set End Time of "SET-BACK" Mode

With the timer selector slide switch in the "END SET-BACK" position, program the end time as described above. (Ex. AM 6:00)

Important: Always return timer selector to "CLOCK/TEMP (NORMAL POSITION)" after settings.

3. Set Room Temperature

Slide "NORMAL" temperature selector and "SET-BACK" temperature selector at the position you desire. (Ex. "NORMAL" — 75°F, "SET-BACK" — 60°F)

Note: The temperature setting currently being used is displayed on the digital indicator. To view and set the Set-Back temperature setting, press the "MINUTE" button for more than three (3) seconds. The display will go back to the Normal temperature setting after ten (10) seconds.

4. Push in AUTO switch to "ON" position.



5. Turn Power ON

Press ON/OFF switch to "ON" position. ON/OFF lamp will start to flash and AUTO switch lamp will light. And then blower motor and ignition will start.

Note: "SET-BACK" OPERATION IRREGULARITIES: If a heater is switched "OFF"; if the "AUTOMATIC" operation is switched off; or if there is a power interruption while the unit is operating in the "SET-BACK" mode, the "SET-BACK" mode may be temporarily disabled until the next Start Set-Back time.

TURNING HEATER OFF

Press ON/OFF switch to "OFF" position. (AUTO lamp and temperature lamp will go out. Burning mode lamp will flash until flame disappears.) Circulation fan and blower motors continue to run for approx. three (3) minutes to cool down the heater. Make sure ON/OFF lamp goes out when the fan stops.



Note: If ON/OFF switch is pressed to "ON" position during the cool down period, the heater will automatically re-start at the end of cool down period.

Note: Disconnect the heater plug from the electrical outlet after the power lamp has turned off if the heater will go unused for a prolonged period. The plug should also be disconnected during electrical storms.

Note: Heater may also be shut down by lowering the setting on the temp. selector thermostat(s) because heater goes into "OFF" cycle.

MANUAL COMBUSTION

Important: This feature is for testing purpose only!

This heater also can be kept burning at desired combustion mode (High, Medium or Low) manually, regardless of room temperature.

1. Press the "HOUR" button and "MINUTE" button at the same time for more than three (3) seconds when ON/OFF switch is "ON".
2. P1, P2 or P3 will be displayed on the Digital Indicator;
P1 = Low mode
P2 = Medium mode
P3 = High mode

Then select desired combustion mode by pressing either "MINUTE" or "HOUR" button. "MINUTE" button changes combustion mode to higher; "HOUR" button changes combustion mode to lower.


3. To clear, press the "HOUR" button and "MINUTE" button at the same time for more than three (3) seconds until normal temperature display returns.

SECTION F: ROUTINE MAINTENANCE

CAUTION: Be sure to unplug heater before performing any checks or cleaning.


CAUTION: Allow heater to cool completely before cleaning or maintenance.

FOR OPTIMUM HEATER PERFORMANCE, THE PARTS SHOWN BELOW SHOULD BE CLEANED REGULARLY:




1. Clean Louvers (ONCE A WEEK)

Dust and stains should be wiped off louvers with a damp cloth.




2. Clean Circulation Fan Cover (ONCE A WEEK)

Remove any dust or pet hair from the fan cover on the back of the heater.




3. Check for Kerosene Leaks (REGULARLY)

Make it a habit to check for any sign of kerosene leakage along the fuel line and at all joints. Kerosene leaks may lead to risk of fire.



4. Check Flue Pipe Area (ONCE A WEEK)

Check the flue pipe joint to make sure connection is firm. Use a vacuum cleaner to remove any dust or pet hair.






5. Clean Fuel Strainer (ONCE A MONTH)

The strainer of the fuel sump should be cleaned once a month and before storing heater at the end of each season.

- (a) Open the door on the right side of cabinet.
- (b) Turn knob of the fusible link valve clockwise to close the fuel line.
- (c) To catch the fuel which will drain out, set the oil catch below the strainer cover, with a small container under it.
- (d) Loosen the two screws from the strainer cover and remove.
- (e) Remove the strainer and wash with kerosene.
- (f) Return the strainer to its original position. Replace strainer cover and screw to secure.
- (g) Wipe away any spilled kerosene.
- (h) Turn the knob of the fusible link valve counterclockwise to open. Check for kerosene leakage.

Note: Be sure to unscrew the drain screw to remove all remaining kerosene from the fuel sump at the end of each season.



SECTION G: TROUBLESHOOTING

NOTE BEFORE REQUESTING FOR REPAIR AND SERVICES

The following symptoms are normal during operation of the heater.

	CONDITION	REASON
When heater is started or extinguished.	White smoke or smell at initial use after purchase.	Machine oil or dust burns of the surfaces of the burner or heat exchanger.
	Flames flashing for a few minutes after ignition.	The burner is cold and igniter is kept running for a while after ignition.
	Occasionally makes "cracking" noise when heater is ignited or extinguished.	Expansion and shrinkage of metal parts when they are heated or cooled.
	Warm air will not blow as soon as ignited.	To prevent uncomfortable cool air from coming out at the beginning, circulation fan start up is delayed.
	Audible chugging sound from fuel pump when started first time or after running out of fuel.	Air is in the pump. However, noise should stop within 1 minute.*
When heater is in operation.	"Ticking" noise.	Noise of fuel pump in operation. Normal.
	Part of the heat chamber or the heat exchanger is heated to a cherry red color.	Normal.
	Occasional yellow flickering in blue flame.	Normal.

*If sound from fuel pump does not decrease and heater shuts off, check:

1. Push red reset button on constant level valve. DO NOT hold down.
2. Insure that all valves are open and filter is clear.
3. Insure external fuel tank has fuel and filters are clean.

AUTOMATIC CLEANING SYSTEM

Heater will automatically clean igniter for ten (10) minutes every day at 2:00 a.m. and display "CL:10" on Digital Indicator if heater is running at that time.

MANUAL CLEANING SYSTEM

Heater will clean igniter for ten (10) minutes manually.

1. Press the "HOUR" button and "MINUTE" button at the same time for more than three (3) seconds when ON/OFF switch is "OFF".
2. Display will appear "CL:10" on Digital Indicator. Cleaning will begin and end without any additional input.

Note: Cleaning igniter is important to prolong igniter life. It is recommended that the igniter be cleaned once a week.

Should problems arise during operation or ignition, use this chart to determine the cause and the proper steps to take. Be sure to unplug heater and allow to cool completely before taking corrective measures. In the event that heater should extinguish itself, without any action on your part, you should look to the digital indicator for any of the following error codes.

DISPLAY/LAMP	PROBLEM	CAUSE	SOLUTION
	POWER LAMP FAILS TO TURN ON	Disconnected power plug Circuit board malfunction	Plug into 120V AC outlet. Consult your dealer.
EE2 EE2 EE2	NO IGNITION	Out of fuel Fuel tank valve closed Air pocket in fuel line	Check fuel gauge on fuel tank; refuel. Open valve by turning counterclockwise. Push reset button on the fuel sump, located right inside, once.
EE2 EE2 EE2		Clogged flue pipe Clogged fuel strainer Igniter, circuit board, flame sensor or fuel pump malfunction	Clean flue pipe. Clean fuel strainer (See page 13). Consult your dealer.
EE8		Blower motor malfunction	Consult your dealer.
EE6 EE6 EE6		Air pocket in fuel line Out of fuel High limit switch activated	Push reset button on the fuel sump, located right inside, once. Check fuel gauge on fuel tank; refuel. Clean circulation fan cover, remove any obstructions.
EE6 EE6 EE6 EE6 EE8		Fuel flow obstruction Tank too high Fuel sump valve malfunction Flame sensor malfunction Blower motor malfunction	Consult your dealer. Re-locate fuel tank. Consult your dealer. Consult your dealer. Consult your dealer.
	POOR COMBUSTION/ NOISY COMBUSTION	Soot buildup in flue pipe Burner ring not properly seated Altitude too high (See page 23.)	Clean out any soot. Consult your dealer. Consult your dealer.
EE10	DOES NOT EXTINGUISH	Possibly excess fuel in burner Flame sensor malfunction	Consult your dealer. Consult your dealer.
	ODOR	Leaking flue pipe Kerosene leakage Faulty packing or gasket in com- bustion area	Tighten all flue pipe connections. Tighten all fuel line joints. Wipe away any kerosene drippage. Consult your dealer.
Hi		Room temp is over 95°F. Incorrect location of room temp sensor	Correct the location of the room temp sensor.
Lo		Room temp is lower than 14°F. Room temp sensor malfunction or disconnected	Check room temp sensor.
Low/Med/ High lamps flashing at the same time	DOES NOT EXTINGUISH	Possibly excess fuel in the burner or flame sensor malfunction (miss detection)	Consult your dealer.

WARNING : Do not re-use the unit until the cause of the "EE10" code has been determined.

If the corrective measures outlined above do not solve the problem, please consult your TOYOSTOVE dealer.


SECTION H: LONG TERM STORAGE

At the close of each heating season, or when you do not plan to use your heater for an extended period, the following procedures are recommended.

1. As the end of the season approaches, calculate your kerosene purchases so that you can use up all the kerosene you have on hand. When kerosene is stored for over six months, its quality may deteriorate. The use of such kerosene will have an unfavorable effect on heater operation.
2. If your heater needs any service or repair, now is the time to call your dealer and get it done before storage. That way your heater will be ready for immediate use when the next heating season begins.

3. If you plan to store your heater in place,

- (a) Unplug heater.
- (b) Close the main tank valve.
- (c) Remove all kerosene from the fuel sump and clean the fuel strainer (see page 13).
- (d) Wipe off any stains or dust on heater with a damp cloth, then wipe once again using a dry cloth.
- (e) Cover heater completely with a large plastic bag to protect from dust.




4. To store heater in another location,

- (a) Unplug heater.
- (b) Close the main tank valve.
- (c) Remove all kerosene from the fuel sump and clean the fuel strainer (see page 13).
- (d) Disconnect fuel line and flue pipe from the heater.

Note: Kerosene remaining in the fuel line may flow out when fuel line is disconnected. Have a container ready to catch drainage.

- (e) Remove any soot accumulated in the flue pipe using a brush and/or vacuum cleaner.
- (f) Wipe off any stains or dust on heater with a damp cloth, then wipe once again using a dry cloth.
- (g) Put the heater and flue pipe in the original shipping box, and store in a dry place. If original shipping box is not available, cover the heater completely with a large plastic bag to protect from dust during storage.
- (h) Plug inner and outer sleeve openings using the two optional sleeve caps (Part # 20474978).



SECTION I: INSTALLATION

TOOLS NEEDED FOR INSTALLATION

Tool


Phillips Head Screwdriver
Electric Drill
Hole Saw, 3½" diameter
Hacksaw (with a 32 teeth/inch blade)

Use


Installation of flue pipe, etc.
Drilling hole in wall for flue pipe
Making hole in wall for flue pipe
Cutting wall sleeve

STANDARD INSTALLATION PARTS


The following standard installation parts are enclosed with heater. For alternate installation methods, you may need to purchase additional accessories which are available from your TOYOSTOVE dealer. See "Accessory Parts", page 19.




Drip tray (1) (PART #20475929)




Wall Brackets (2 sets) (PART #20474962)













Exhaust Extension pipe (S) (1) (PART #20474956)



Pipe stopper (1) (PART #20474964)



Pipe holder (2) (PART #20474963)

 <p>Standard Flue Pipe (1) (PART #20478501) Exhaust Air Cap (1) (PART #20474945) Intake Air Cap (1) (PART #20474949)</p>	 <p>Wall Sleeve and Sleeve Nut (1 ea.) (PART #20479867)</p>
 <p>Bent Joint (1) (= Part #22744961 L-shaped exhaust pipe)</p>	 <p>(PART #20474968) (PART #20474969) Inner and Outer Sleeve Flange (1 ea.) w/screws</p>
 <p>Oil Catch (1) (PART #20474925)</p>	 <p>Flue Pipe Gasket (1) (PART #20474974)</p>
 <p>Flange Gasket (2) (PART #20474971)</p>	 <p>L-Shaped Hose (2) (PART #20474975)</p>
 <p>Inlet Hose (1) (PART #20474951)</p>	 <p>Hose Band (2) (PART #20474977)</p>


ACCESSORY PARTS

The following accessory parts are available for use in non-standard installation of the Laser 56. After giving careful consideration to your desired heater and flue pipe locations and fueling system, consult your TOYOSTOVE dealer to purchase the necessary accessory parts.

Important: Use only genuine TOYOSTOVE parts for you heater. Use of unauthorized generic or other brand parts can severely reduce performance and safety, and will invalidate factory warranty.


Accessory	Part No.	Application
Extension pipe kit (L)*	22744998	Extends pipe system by 61-3/4 to 78-3/4"
Extension pipe kit (M)*	22744997	Extends pipe system by 22-1/2 to 39-3/8"
Extension pipe kit (S)*	22744996	Extends pipe system by 12-5/8 to 19-5/8"
L-Shaped exhaust joint*	22744961	For 90 degree bend in exhaust pipe
Electric Kerosene Lifter Model OPT-81UL	22744990	Used to lift fuel to heater when fuel tank is located underground or outdoors in a position lower than the heater. With automatic recovery.
Window Kit (L)	20475589	for installation fo flue pipe in windows from 31 to 50 inches wide.
Window Kit (S)	20475588	For installation of flue pipe in windows from 20 to 32 inches wide.
Long flue pipe	20479857	For installation in wall thicknesses 18 inches.
External Fuel Supply Installation Kit	10005098	For installation of external tank system
Weekly Set-back timer	20478302	Weekly programmable timer to control ON/OFF of SET-BACK mode

* Total length of extension pipe between heater and flue pipe must be no greater than 10 ft. No more than three bends may be used in extension pipe.




EXTENSION KIT

Extension Pipe Kit (L) PART #22744998




No.	Name of Part	Qty.
①	Adjustable Exhaust Pipe Max. 39- $\frac{3}{8}$ ~ 22- $\frac{7}{16}$ inch	1
②	Exhaust Extension Pipe (long, 39- $\frac{3}{8}$ inch)	1
③	Intake Pipe 80 inch	1
④	Insulating cloth cover (40 inch)	2
⑤	Pipe Holder	2
⑥	Pipe Support Hardware	3 sets
⑦	L-Shaped Exhaust Joint	1

Figure 1




When using the "Extension pipe kit (L)", the distance between the heater exhaust pipe connection and the flue pipe connection must be at least 63- $\frac{5}{8}$ inch but no more than 80- $\frac{1}{2}$ inch. (see Figure 1 for reference)

INSTALLATION WITH EXTENSION PIPE KIT (L)




NOTE: Use "L"-shaped Exhaust Joint if necessary.

Extension Pipe Kit (M) PART #22744997




No.	Name of Part	Qty.
①	Adjustable Exhaust Pipe Max. 39- ³ / ₈ ~ 22- ⁷ / ₁₆	1
②	Intake Pipe 40 inch	1
③	Insulating cloth cover 40 inch	1
④	Pipe Holder	2
⑤	Pipe Support Hardware	2 sets
⑥	L-Shaped Exhaust Joint	1

Figure 1




When using the "Extension pipe kit (M), the distance between the heater exhaust pipe connection and the flue pipe connection must be at least 25-⁵/₈ inch but no more than 42-¹/₂ inch. (see Figure 1 for reference)

Extension Pipe Kit (S) PART #22744996



No.	Name of Part	Qty.
①	Adjustable Exhaust Pipe Max. 19- ¹¹ / ₁₆ ~ 12- ⁵ / ₈	1
②	Intake Pipe 20 inch	1
③	Insulating cloth cover 40 inch	1
④	Pipe Holder	2
⑤	Pipe Support Hardware	1 set
⑥	L-Shaped Exhaust Joint	1


Figure 1




When using the "Extension pipe kit (S), the distance between the heater exhaust pipe connection and the flue pipe connection must be at least 15-³/₄ inch but no more than 22-³/₄ inch. (see Figure 1 for reference)

WINDOW KIT

Window Kit (L) PART #20475589 Window Kit (S) PART #20475588




Ex. Window Kit




SAFETY TIPS FOR INSTALLATION

Follow the safety tips below when planning the installation of your Laser 56.


1. Intake and exhaust flue pipe openings must be fully exposed to outside air. Do not vent into garage, basement under the floor, or into any enclosed area.



2. Do not install flue pipe in close proximity to other objects or materials (see page 23).




3. Before making a hole in your wall for the flue pipe, make sure the area is free of electrical wires, gas pipes and other obstacles.



4. Do not install flue pipe where it will be exposed to heavy snow collected leaves or strong drafts.



Important:

In areas of heavy snow falls, ground surface clearance must be increased according to average snow falls.






Important:

In open area with strong wind, a wind break may be necessary.




5. Do not install the flue pipe down from the heater nor into chimney.



6. Total length of extension pipe between heater and flue pipe must be no greater than 10 ft. and 3 bends may be used.

NOTE: When using extension pipes always cover the exhaust pipe with the insulating cloth cover.



INSTALLATION OF HEATER AND FLUE PIPE

IMPORTANT: Check and comply with all state and local codes that may apply to vented heaters before beginning installation.

NOTE: This heater is designed to be used no more than 3000 FT. above sea level.
ASK your local dealer for using at altitudes higher than 3000 FT. above sea level.

1. Select heater location. Allow clearances as indicated below between heater and all other materials.
(See Fig. 1)




Fig. 1

2. Make sure that the outside area to where the flue pipe will reach is clear of any objects.
(See Fig. 2 & 3)

NOTE: Make sure wall thickness is not greater than 10 inches. If it is more than 10 inches, consult with your local dealer. A longer flue pipe will be available through your dealer or distributor.

NOTE: Flue pipe can be installed through any standard building materials. Please ask your local dealer or distributor for more details.




Fig. 2





Fig. 3



3. For standard installation, use the template enclosed with the heater to position the hole for the standard flue pipe. Tack or tape template to the wall at the desired position (See Fig. 4).



NOTE: Heater should be installed on a sturdy floor that is level and flat.


NOTE: The template can be adjusted for use of non-standard installations such as the use of extension pipe kits.

4. Cut the hole for the standard flue pipe from inside the room. Use a 3-1/2" diameter hole saw attached to an electric drill (See Fig. 5). The opening on the inside wall should be slightly higher than the outside opening (approximately 1/2") so that the wall sleeve and the standard flue pipe will slope slightly downward (approximately 3 degrees) after it is installed (See Fig. 6). This will enable the draining of condensed moisture from the standard flue pipe to the outside and prevent rain or snow entering from outside after installation.




NOTE: After the cutting of the hole is completed, remove the template from the wall.

5. a. Install the inner sleeve flange and the flange gasket to the wall sleeve and insert the wall sleeve through the wall hole from inside the room. Make sure the arrow on the inner sleeve flange is pointing up. Secure the inner sleeve flange to the wall with the three wood screws provided with the heater (See Fig. 7).



- b. From outside, install the outer sleeve flange and the flange gasket to the wall sleeve. Secure the wall sleeve and the outer sleeve flange tightly with the sleeve nut. Make sure arrow on the outer sleeve flange is pointing up (See Fig. 8).



6. From inside the room, insert the standard flue pipe with gasket attached through the wall sleeve. Secure the standard flue pipe to the inner sleeve flange with the three machine screws provided with the heater (See Fig. 9).




Fig. 9

NOTE: Make sure the standard flue pipe slopes slightly downward after it is installed. This will enable the draining of condensed moisture from the standard flue pipe to the outside and prevent rain or snow entering from outside after installation.




Fig. 10

7. Insert the bent joint to the exhaust mouth of the standard flue pipe. Cut the inlet hose for desired length if necessary. Attach the L-shaped hose to each end of the inlet hose and attach the L-shaped hose to the intake mouth of the standard flue pipe. Secure the L-shaped hose to the intake mouth with the hose band. Plug the unused exhaust and intake mouth with the caps provided with the heater. Make sure the caps fit tightly onto the mouth (See Fig. 11).




Fig. 11

Note: If the inlet hose is not smoothly inserted into the L-shaped hose, apply water or soap suds to the inlet hose.

8. In case the circuit board cover gets in the way of the connection of the standard flue pipe, use the extension pipe (S) for the exhaust outlet mouth of the heater (See Fig. 12).




Fig. 12

9. Move the heater into position. Connect the bent joint to the exhaust outlet mouth (upper opening) and attach the L-shaped hose to the intake inlet mouth. Make sure all connections are tight (See Fig. 13).




Fig. 13

10. Secure the L-shaped hose to the intake inlet mouth with the hose band. Secure the bent joint to the standard flue pipe with the pipe holder (If the extension pipe is used, also attach the pipe holder to the connection of the bent joint and the extension pipe). Secure the bent joint (or the extension pipe) to the exhaust outlet mouth by sliding the pipe stopper in the exhaust mouth bracket (See Fig. 14).





Fig. 14

11. Make sure the position of the heater is level by using the plumb bob located at the right side of the heater. The plumb bob weight should be within the circle. If the plumb bob weight is not within the circle, adjust the heater legs until the plumb bob weight is within the circle (See Fig. 15 & 16).



Plumb bob as viewed from above

Fig. 15





Fig. 16

12. A room temperature sensor is provided with approximately 8 feet long extension wire. It is located on the rear of the cabinet. Make sure that the extension wire is not touching the exhaust pipe. The room temperature sensor can be installed either with the self adhesive tape on the back or with a wood screw provided with the sensor depending on the type of surface chosen for installation.

Note: Choose a location for the sensor that is not in the path of direct sunlight, drafts or the flow of warm air from the heater.


(a) Self Adhesive Tape

Peel off the protective tape on the back of the sensor and expose the adhesives. Place the sensor on the desired location on the wall and press down.



(b) Wood Screw

Screw down the wood screw provided with the heater into the desired location on the wall. Hook the back of the room temperature sensor.



13. After installation is completed, secure heater to the wall with the wall brackets provided with the heater. Make sure the heater is parallel to the wall (See Fig. 17).




Fig. 17


14. Before ignition, recheck the following:

- a) All connections are tight and firm.
- b) The heater and the standard flue pipe areas are free of any materials.
- c) The heater is level and parallel to the wall.
- d) The exhaust and the intake holes of the standard flue pipe are fully exposed to outdoor air, but not protruded too far from the wall sleeve.


PERMANENT WIRING INSTALLATION

WARNING: MAKE SURE POWER SUPPLY CORD IS DISCONNECTED TO AVOID ANY ELECTRIC SHOCK BEFORE SERVICING. ELECTRIC SHOCK MAY CAUSE SERIOUS INJURY. INSTALLATION SHOULD BE CONDUCTED BY A LICENCED ELECTRICIAN.


Step 1.
Disconnect power supply cord from power source. Remove three (3) screws and control box cover on the back of the heater.




Step 2.
Disconnect ground wire (green wire) from the power supply cord bracket.




Step 3.
Disconnect two power supply wires from right side of the terminal.




Step 4.
Squeeze strain relief with the adjustable pliers to remove plastic bushing from the power supply cord bracket. Remove the power supply cord.



Step 5.
Insert the power supply cable from junction box and connect ground wire to the power supply cord bracket and power wires to the terminal.



Step 6.
Affix the control box cover to the heater and insert screws.



NOTE: Emergency power supply and use of 12V DC batteries and an inverter. Consult your dealer before attempting to use a battery/inverter system to provide power for your Laser heater. These units require true sine wave power for proper long-term operation. Some modified sine wave inverters can be used to provide short-term emergency power but some types of modified sine wave inverters will cause damage to the electrical components of the heater. Several inverter manufacturers offer true sine wave inverters which should operate the unit without any problems if properly sized and configured. If you have any questions about appropriate power supply, consult your authorized TOYOSTOVE dealer.

SECTION J: FUELING

WARNING: Use only water-clear No. 1-K kerosene. NEVER USE GASOLINE. Use of gasoline can lead to uncontrollable flames resulting in destructive fire.

Laser 56 FUEL SYSTEM OPTIONS

● Large Capacity External Tank

Tank must be purchased separately and installed by a qualified fuel supply technician.

EXTERNAL TANK INSTALLATION

Note: External tank installation must comply with National Fire Protection Association Code NFPA 31 or locally applicable codes. Check with local building officials.


The following instructions should be followed for installation of a large capacity, gravity-fed external fuel tank.

- Installation height of tank's fuel outlet should be at least 16 in. above floor surface upon which heater rests.
- To avoid excess fuel pressure to heater, top of fuel tank should be no more than 8½ ft. above floor surface upon which heater rests.
- Fuel tank should be located at least 6 ft. away from all heat sources.
- 3/8" OD copper tubing should be used for fuel line.
- To prevent air locks in fuel line, fuel line should be smooth with no U-shaped or sharp bends.
- Use of fuel filter in fuel line adjacent to tank is recommended, shut-off valves should also be installed on the fuel line and connected to the tank as shown below.

Note: An additional shut-off valve installed next to the exterior wall will minimize fuel to be drained should heater have to be disconnected. If the valve is on interior side, a fusible link type is recommended.

1. Be sure all external tanks have an operating vent.
2. The use of a water trap filter is recommended. A model with a drain plug or petcock is preferred.
3. Be sure to observe the maximum and minimum tank heights as specified.

Note: If the maximum height is exceeded, a fuel pressure limiting valve is required. A suitable unit is available through N.A.P.A. stores. Part No. 7302568 comes with 3/8-in. fittings. The rubber connectors may be discarded.



LIMITED WARRANTY

TOYOTOMI U.S.A., INC. ("TOYOTOMI") warrants each product and any parts thereof sold by it to be free from defects in materials or workmanship under normal use and service for TWELVE (12) MONTHS* from the date of delivery to the original purchaser at retail subject to the following terms and conditions :

WHAT IS COVERED : Product or any parts thereof which are defective in materials or workmanship

WHAT IS NOT COVERED :

(1) This warranty does not extend to any defect due to the negligence of others: failure to install, operate or maintain unit in accordance with installation instructions (operating and maintenance instructions are furnished with each new unit) : unreasonable use, accidents, alteration, use of unauthorized or non-standardized TOYOTOMI parts and accessories; electrical malfunction, i.e., as resulting from large power surges, short circuit, etc.; incorrect installation; use of any fuel other than that specified in owner's manuals; or repair by anyone other than a service facility specified by TOYOTOMI.

(2) Normal wear and tear of parts, including wicks, batteries, igniter coils and siphons, hoses, wires, burner mats, filters and accessories.

(3) This warranty does not cover shipping costs.

WHO IS COVERED : The ordinal purchaser at retail.

WHAT WE WILL DO : TOYOTOMI will either repair or replace, at its option, all defective parts free of charge that are covered by this limited warranty on a carry-in basis, to your nearest authorized dealer or distributor of TOYOTOMI.

WHAT YOU MUST DO FOR WARRANTY SERVICE : You must return the defective Product or part to any authorized dealer or distributor of TOYOTOMI with this LIMITED WARRANTY and a copy of your bill of sale or credit card charge receipt or other documents evidencing the date of the Product's delivery, if service is not available locally, please contact our CUSTOMER RELATIONS DEPARTMENT at :

TOYOTOMI U.S.A., INC.
604 Federal Road, Brookfield, CT 06804
(203)775-1909

THE FOREGOING EXPRESSES ALL OF TOYOTOMI'S OBLIGATIONS AND LIABILITIES WITH RESPECT TO THE QUALITY OF PRODUCT FURNISHED BY IT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. TOYOTOMI SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL ARISING OUT OF, THE USE OF, OR INABILITY TO USE, THE PRODUCT OR DAMAGES RESULTING FROM OR ATTRIBUTABLE TO DEFECTS IN THE PRODUCT.

No one other than TOYOTOMI has authority to extend or modify the terms of this Limited Warranty in any manner whatsoever.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so these limitations or exclusions may not apply to you. This Limited Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

* In addition to the warranty period stated above, an extended two (2) year warranty is offered for the following :

1. Vented Heater :

- A. Burner Pot
- B. Radiant Chamber
- C. Heat Exchanger

2. Hot Water Heater :

- A. Burner Assembly
- B. Heat Exchanger Assembly

NOTE : THE EXTENDED WARRANTY POLICY IS APPLICABLE ONLY FOR THE REPLACEMENT OF THE ORIGINAL FACTORY-INSTALLED PARTS THAT HAVE FAILED WITHIN THE TIME LIMITATIONS AS INDICATED. REPLACEMENT PARTS ARE WARRANTED FOR THE REMAINDER OF THE ORIGINAL PART WARRANTY PERIOD.

2486002060



TOYOTOMI U.S.A., INC.

P.O. BOX176, Brookfield, CT 06804-0176