




2GIG[®] Security & Automation System

GC2e Z-Wave Installation Guide



Copyright © 2022 Nortek Security & Control LLC. All Rights Reserved. U.S. Patent D727,857. Australian Patent No. 357098. Additional Patents Pending.

The 2GIG®, GC3, GoControl, and Linear logos are trademarks of Nortek Security & Control LLC in the United States and/or other countries. Other Nortek Security & Control trademarks may also appear in these materials. Other names or brands may be claimed as the property of others. For more information, contact your 2GIG alarm dealer for pricing or visit www.nortek.com, www.nortekcontrol.com, or www.2gig.com.

Information in this document is subject to change without notice. The availability of particular products, services, and features may vary by region. Please check with your local dealer for further details and availability of language options.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's personal use without the written permission of Nortek Security & Control.

Nortek Security & Control
5919 Sea Otter Place, Suite 100
Carlsbad, CA 92010
USA
800-421-1587

Contents

Introduction. 3

 Accessing the Z-Wave Toolbox3

 Adding Devices4

 Z-Wave Add Failures5

 Removing Devices6

 Joining an existing Z-Wave Network6

 Z-Wave Security Inclusion Failure8

 Z-Wave Network Check.....9

 Rediscover Z-Wave Network.....9

 View All Devices9

 Renaming Z-Wave Devices.....10

 Add Users to Z-Wave Lock.....10

 Basic Commands11

 Resetting the Z-Wave Network.....12

 Additional Information.....13

Introduction

The 2GIG GC2e Security Panel is also a Security Enabled Z-Wave Plus home automation controller. This product can be operated with other Z-Wave certified devices from other manufacturers. All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase reliability of the network. It is compatible with both Z-Wave Plus with S2 Security and Legacy S0 Z-Wave automation devices.

Accessing the Z-Wave Toolbox

The Z-Wave toolbox is accessed through the services menu from the Home Screen.


» Press the **services** button.



» Press the **Z-Wave** button.




» Press the **wrench** button.




» Enter Installer Code.

Notes:

- » The "default" **Installer Code** is 1561.
- » If Q85 is enabled in system configuration, the master user code may be used to access the Z-Wave Toolbox.



The Z-Wave Toolbox appears.




Adding Devices

- » From the Z-Wave Toolbox, press the **add devices** button.




The panel will begin listening for new Z-Wave Device



Follow the device manufacturing procedure for putting the device into add/remove mode.

When the new Z-Wave device is discovered, the information will be displayed on the learn screen.

Note: If you are adding a legacy S0 device, learning is complete.




- » Enter the Z-Wave Plus devices DSK provided with the devices instructions or on the device itself and press the **SUBMIT** button.



When the learn process completes, the device and node info will be displayed.

- » If all devices have been added, press the **back** button to return to the Z-Wave toolbox.




Z-Wave Add Failures


Inclusion Failure

If a Z-Wave device fails due to a security inclusion failure, the following screen will be displayed:

- » Press the **Remove Failed Devices** button.




- » Select **OK**.




The panel will display the Remove Z-Wave Devices screen.

- » Press the **learn** button on the device to remove the device.




The panel will display confirmation that the device has been removed.




Missing Information

If a device is missing information after its inclusion, the device will display in yellow and will indicate a failure. (Services > Z-Wave > Devices > Switches/Thermostats/Doors and Locks).



Selecting the device will display this message:



To correct the failure:

- » Run “check network” from the “Services > Z-Wave > Devices >” screen.


Note: If running check network does not correct the failure condition, remove and re-add the device to the panel.




Removing Devices

- » From the Z-Wave Toolbox, press the **remove devices** button.

Follow the device manufacturing procedure for putting the device into add/remove mode.



Panel will display when the device has been successfully removed.




Joining an existing Z-Wave Network


- » From the Z-Wave toolbox, press the **advanced toolbox** button..




- » To learn the Panel as a Secondary Controller, press the **learn controller** button.




Panel will show that it has entered Z-Wave shift mode.




- » Enter **Add Controller Mode** on the Primary Controller.
- Panel will display status of shift mode process.



- » Enter **Add Controller Mode** on the Primary Controller.
- Note:** If the controller is S2, the screens that follow will display.
- » Enter the Panel DSK shown on the panel into the existing Controller.
 - » Press the **ok** button.



- Panel will show that the operation was successful.
- » Press the **ok** button to return to Z-Wave Toolbox.



Z-Wave Security Inclusion Failure


If Z-Wave security inclusion fails when attempting to add the panel to another Z-Wave network, the following screens will be displayed:

The Z-Wave button on the Services screen will display red.



Pressing the red Z-Wave button (above) will display the following message.


- » Press the **ok** button.



All Z-Wave devices will be grayed out.




In the Z-Wave toolbox > advanced toolbox > view all devices: Controller will show the inclusion failure in yellow.



To correct this failure:

- » Remove the panel from the other network by following the remove process of the other Controller.
- » Press the **learn controller** button in the advanced toolbox screen on the GC2e panel to remove it from the network.



Z-Wave Network Check

To perform a network check, enter the main Z-Wave Menu.

- » Press the **check network** button.



Rediscover Z-Wave Network


Enter the Z-Wave toolbox.

- » Press the **advanced toolbox** button.



- » Press the **rediscover network** button.

The panel will go into network rediscovery mode and verify all routes and devices are functioning correctly.



View All Devices


- » From the Z-Wave Toolbox, press the advanced toolbox button.



- » Press the **view all devices**.




- » Panel will display a list of all installed devices.




Renaming Z-Wave Devices

- » From the “view all devices” screen tap the device you want to rename.



- » On the “basic device settings” screen, tap the rename button.



- » Enter new name for the device.



Add Users to Z-Wave Lock

Note: This section only applies if Installer Questions Q79 – Z-Wave Feature is set to Option 2 (Enabled on Panel, Remote Access Disabled). If Q79 is set to the default setting 3 (Enabled on Panel, Rules Disabled, Remote Access Enabled) this feature is controlled by the backend provider.


Access the Z-Wave Control

From the Home screen


- » Select Services
- » Select Z-Wave
- » Select Door & Locks
- » Select **codes**).



- » Enter the Master Code.



- » Select a user.




- » Enter a lock code for the user, select **ok**, and then confirm the code and press **ok** again.



You will see a confirmation that the lock code was changed.

- » Select **ok**.



Lock codes will show next to users.

- » Select **back** to return to the Doors & Locks Screen.

Lock codes will show next to users.


- » Select **back** to return to the Doors & Locks Screen.

Note: To remove user access from a lock, press the delete key and confirm by selecting “remove lock code.”




Basic Commands


- » From the “view all devices” screen, tap the device you want to rename).



- » Tap the button in the center of the screen.



- » Enter the value for the basic command (see device documentation for details).
- » Tap **ok**.



The following screen shows the updated entry value (Figure 49).




Resetting the Z-Wave Network

To completely reset the Z-Wave controller, enter the advance Z-Wave toolbox.


Note: If this controller is the primary controller for your network, resetting it will result in the nodes in your network being orphaned and it will be necessary after the reset to exclude and re-include all of the nodes in the network. If this controller is being used as a secondary controller in the network, use this procedure to reset this controller only in the event that the network primary controller is missing or otherwise inoperable.



- » Press the **reset controller** button.




- » Press the **reset controller** button to confirm you wish to reset the controller.



Panel will display confirmation that controller has been reset.

- » Press **ok** to return to Z-Wave Toolbox.



Additional Information

Basic Commands

- » Basic Get commands to the GC2e panel will receive a response of Basic Report Value 0
- » Basic Set commands to the GC2e panel are ignored

Group Identifier

- » Only Group 1 is supported
- » Max number of devices per group: 1

Associations

- » Associations can be set by controllers with the ASSOCIATION_SET command
- » Associations supported commands:
 - » COMMAND_CLASS_DEVICE_RESET_LOCALLY
 - » DEVICE_RESET_LOCALLY_NOTIFICATION

Note: Associations are not controlled/supported through the GC2e UI.

S2

- » Supported Command Classes and Security Levels

Note: GC2e minimum required security level is none.

Command Class	Version Number
COMMAND_CLASS_ZWAVEPLUS_INFO	2
COMMAND_CLASS_MANUFACTURER_SPECIFIC	1
COMMAND_CLASS_SECURITY	1
COMMAND_CLASS_SECURITY_2	1
COMMAND_CLASS_INCLUSION_CONTROLLER	1
COMMAND_CLASS_TRANSPORT_SERVICE_V2	2
COMMAND_CLASS_DEVICE_RESET_LOCALLY	1
COMMAND_CLASS_POWERLEVEL	1
COMMAND_CLASS_CRC_16_ENCAP	1
COMMAND_CLASS_ASSOCIATION_V2	2
COMMAND_CLASS_ASSOCIATION_GRP_INFO_V3	3
COMMAND_CLASS_SUPERVISION	1
COMMAND_CLASS_VERSION_V2	2

Controller Replication

Controller replication is not supported through the panel User Interface. Please consult your backend provider if the replication option is available through the dealer portal.

[THIS PAGE LEFT INTENTIONALLY BLANK]

[THIS PAGE LEFT INTENTIONALLY BLANK]

ALARM DEALER INFORMATION

Company Name:

Your Account Number:

Installation Date:

10023184-001 Rev-B



Technical Support: 1-707-283-5900 • 1-800-472-5555

Contact: www.2gig.com • **Dealers:** 2gig.com/dealers



©2022 Nortek Security & Control LLC. ©2022 Nortek Security & Control LLC. Brand is a registered trademark of Nortek Security & Control LLC. All rights reserved. Nortek Security & Control LLC. 5919 Sea Otter Place, Suite 100, Carlsbad, CA 92010 USA