

# Octo Spray 7 Shower Head Systems

## Contents:

- 1) Shower Flange
- 2) Shower Nipple
- 3) Way Diverter Valve
- 4) Coupling
- 5) High Rise Shower Arm
- 6) Hose
- 7) Flow Control 98% Shut Off
- 8) Handheld Shower Head
- 9) Rain Shower Head
- 10) Shower Slide Bar
- 11) Roll of Teflon Tape (not shown)

Use a Cloth Rag Over Finished Items to Protect Fittings.  
When Using Pliers. Use Smooth Jaw Plier or Wrench.  
You Don't Want to Mar the Fittings!

Wrap Teflon Tape Clockwise Four Times Around Threads Items (2) Shower Nipple Both Ends.  
Screw into Wall Fitting and Tighten.

Screw on Diverter Valve (3) to Shower Nipple (2)  
Screw on (4) Coupling onto Diverter (3) Use Washers to Seal.

Attach Hose (6) to Diverter (3) and to (7) 98% Flow Control.  
Make Sure Rubber Hose Washers and Teflon Tape Are Used.

Screw on High Rise Shower Arm (5) to (4) Coupling.  
Handheld (7) into 98% Flow Control. Attach Handheld Shower Head.  
Wrap Teflon Tape Around Threads For Times (5) Attach Rain Shower Head.

## Item (10) Shower Bar:

Locate Socket (A) at a Suitable Height. Drill Hole and Insert anchor in wall.  
Place the Screw through the Socket and Tighten Firmly.

Locate Socket (B) 24" below from Center Holes of Sockets. Drill hole and Insert Anchor in Wall. Place the Screw through the Socket and Tighten firmly.

Attach bracket (D) to socket (A). Tighten Hex Set Screw (C) to hold in place.

Attach Bracket (B) to Socket (F). Tighten Hex Set Screw (C) to hold in place.

Place Hand Held Shower Head in (E) Adjustable Shower Head Swivel Connector.

