

How To Refinish VCT Chemical Free

What You Will Need

- Square Scrub Machine
- Dry Vacuum Kit (or other vac)
- SQP Pads
- Floor Finish
- Driver Pad
- Bucket on a Stick
- Extra Microfiber Heads(BOS)

- **Note:** Carefully read all instructions prior to starting this process.
- **IMPORTANT:** Make certain your work area has been swept and cleared of debris that may harm the floor's surface or machine.
- **IMPORTANT:** Make certain a driver (or spacer) pad is used between the machine and your SQP. Check both the SQP and driver pad for wear and replace as needed.

1. Set the SQP pad against the wall. Lower the machine onto the pad centering the machine on the SQP pad.

2. If you are using a Square Scrub Dry Vacuum Kit, attach it now (if not already attached). If you are using a different vacuum system, plug the vacuum hose into the coupling behind the handle.

3. Make 2 passes at a rate of 1 to 2 feet per second.

Note: Square Scrub recommends vacuuming finish within 15 minutes. Limit the floor traffic on the surface to avoid the powdered finish to be ground back into the surface.



SQP Pad



4. Vacuum up debris on the floor with a vacuum that has a rotating beater bar to dislodge any finish that may try to stick to the surface. Vacuum the entire surface.



5. With a Bucket on a Stick (or other mop) damp mop the entire surface with water only. Allow to dry and check for residue. Repeat until surface is clean.



When dry and free of residue, apply finish per manufacturer's recommendation. Change the mop head on the Bucket on a Stick and pour finish into the tank or use a fresh mop.



800-557-6822
www.squarescrub.com