

# WOCA DIAMOND OIL Active APPLICATION INSTRUCTIONS

WOCA Diamond Oil ensures an extremely hard wearing, dirt and water repellent surface. It may be used on all unfinished flooring and woodwork, including surfaces finished with all WOCA pretreatments. Diamond Oil Active is available in several colors.

## Work Instructions:

1. The unfinished flooring or woodwork must be sanded to grit 100-120 and be clean and dry. Minimum room temperature during application should be 60 degrees.
2. Wash floor with WOCA Wood Cleaner and let dry completely (see Wood Cleaner instructions).
3. Shake oil container well before and during use. Containers with different batch numbers should be mixed before use to prevent potential color differences. Using a paint tray and paint roller, apply an even coat of oil on approx. 50-100 sq.ft. of flooring. For edges and corners use paint brush.
4. Leave the oil to absorb for 10-15 minutes. If dry spots appear, apply more oil.
5. Slowly polish the area with a floor machine and white or beige pad until floor appears saturated.
6. Polish off all excess oil from floor using cotton cloths under the pad. Hand wipe all edges and corners. No excess oil should be left on the surface.
7. If an extra-attractive finish and resistance is desired, apply 3 oz of Diamond Oil Active per 100 sf within 6-12 hours of the first application. The oil should be polished thoroughly, as described in step 5 and 6.
8. The floor can be used with caution after 24 hours. Do not expose floor or woodwork to water during hardening time, approx. 3-5 days.
9. After 5-7 days, clean floor with WOCA Soap or Oil Refresher to provide additional protection against wear and tear.

**Tip:** For fastest drying time, leave windows slightly open to ensure a steady flow of fresh oxygen.

**Warning!** Rags, pads or waste soaked with WOCA oil may self-ignite if improperly discarded. Immediately after use, place all rags and waste in a sealed, water filled bucket for proper disposal.