

WOCA DIAMOND OIL APPLICATION INSTRUCTIONS

WOCA Diamond Oil ensures an extremely hard wearing, dirt and water repellant surface. It contains less than 1% solvent and may be used on all unfinished flooring and woodwork, including surfaces finished with all WOCA pretreatments. Diamond Oil is available in several colors.

When applied using WOCA Patina Discs, Diamond Oil is a perfect single coat oil finishing system for residential use.

Work Instructions:

- 1. The unfinished flooring or woodwork must be sanded to grit 100-120 and be clean and dry. Minimum room temperature during application should be 60 degrees.
- 2. Wash floor with WOCA Wood Cleaner and let dry completely (see Wood Cleaner instructions).
- 3. Shake oil container well before and during use. Containers with different batch numbers should be mixed before use to prevent potential color differences. Using a paint tray and paint roller, apply an even coat of oil on approx. 50-100 sq.ft. of flooring. For edges and corners use paint brush.
- 4. Leave the oil to absorb for 5-10 minutes. If dry spots appear, apply more oil.
- 5. Slowly polish the area with a floor machine and red pad until floor appears saturated.
- 6. Polish off all excess oil from floor using cotton cloths under the pad. Hand wipe all edges and corners. No excess oil should be left on the surface.
- 7. When entire floor has been finished, polish it well using WOCA Wool Pads under floor machine.
- 8. Note: If Patina Discs were used the floor in now finished! If not, proceed with steps 9 and 10.
- 9. After 12 hours, the floor can be treated with a second application of oil. Approx. 1 ounce of Diamond Oil is poured onto the surface and carefully polished into the floor. Repeat until entire floor is done. Remove any excess oil from the surface.
- 10. After polish floor with WOCA Wool Pads.
- 11. The floor is ready for light wear after 24 hours.
- 12. Do not expose floor or woodwork to water during hardening time, approx. 3-5 days.
- 13. After 5-7 days, clean floor with WOCA Soap or Oil Refresher to provide additional protection against wear and tear.

Tip: For fastest drying time, leave windows slightly open to ensure a steady flow of fresh oxygen.

Warning! Rags, pads or waste soaked with WOCA oil may self-ignite if improperly discarded. Immediately after use, place all rags and waste in a sealed, water filled bucket for proper disposal.