TIPS FOR

BATHROOM LIGHTING

Lighting for Powder Rooms to Master Baths

BATHROOMS CAN REQUIRE MANY LAYERS OF LIGHT - OVERHEAD, ABOVE THE VANITY, IN THE BATH, SHOWER AREA AND IN THE WATER CLOSET. IN A POWDER ROOM, YOU MAY BE ABLE TO USE JUST A SINGLE FIXTURE IN THE CENTER OF THE ROOM OR MOUNTED ABOVE THE MIRROR. WHILE A MASTER BATHROOM AND OTHER BATHROOMS WHERE PEOPLE WILL BE DRESSING AND GETTING READY FOR THEIR DAY WILL REQUIRE MORE LIGHTING



Astro Collection



Paxton Collection



Hampton Collection



Bathrooms can require many layers of light overhead, above the vanity, in the bath and shower area and in the water closet.

In a powder room, you may be able to use just a single future in the center of the room or mounted above the mirror.

While a master bathroom and other bathrooms where people will be dressing and getting ready for their day will require more lighting.

A good rule of thumb when lighting a vanity area is to aim to fully surround the face with flattering light.

You can do this by installing a fixture that is at least 24 inches wide above the vanity mirror (for a single vanity.) Combine that with a pair of sconces mounted on either side of the mirror, at least 28 inches apart and 5 feet above the floor.