




2-Door Cabinet Assembly Instructions





Applies Towards:

Tools Needed:

FL/ML/MJ/WH2013 WH2013A

-Phillips Screwdriver -A Helper

FL/ML/MJ2052

List of Hardware:

Wood Dowel	Shelf Pin	Hinge	
800			
Cam Pin	Plunger Lock	Hinge Plate	
Cam Lock	Leveling Glide	Lock/Key	
	\bigcirc		
Door Pull	Shallow Cover	Deep Cover	

Step 1.) For 2013 and 2052 cabinets only. Attach Toe Kick to Bottom Panel with cam pins & locks. Assemble upside down.

Step 2.) (For all cabinets) Attach Back Panel to Bottom Panel with cam pins & locks.

Step 3.) Attach Left & Right Side Panels in same manner.

Step 4.) Attach Top Surface with cam locks, cam pins and dowels. Then, insert the four leveling glides.


Step 5.) Insert shelf pins into holes along the interior sides. Place Shelf on top of the pins.

Step 6.) Attach four hinge plates with the screws included. The holes are piloted. DO NOT TIGHTEN ALL OF THE WAY! LEAVE WIGGLE ROOM FOR ADJUSTMENT LATER ON.

Questions? Please call 1-800-443-5117.

Customer Service available 8:30 - 5:00 Central Time, Monday - Friday

Special Note:



Step 7.) Attach two hinges per door. The holes are piloted. Then, insert the hinges into the hinge plates inside the cabinet. Connect with screws.

Step 8.) Attach the door pulls with the screws included. Insert shallow & deep covers over cam lock holes. Deep covers are for interior cams, shallow are for the back panel cams.

Step 9.) Once you have the cabinet in the place you intend to use it, it will be time to adjust the hinges to align the doors. Using your screwdriver, turn the set screw on the hinge to adjust the depth and the screws on the hinge plate to move the door up/down. See diagram above.

Step 10.) Your last step is to insert the shallow & deep covers over the cam locks and to attach the plunger lock and lock core. Locate the pre-drilled notch on the underside of the Top Surface. Attach plunger lock so it inserts into the notch when pushed in. Attach the lock core with four screws provided.




2, 3 & 4 Drawer Lateral File Assembly Instructions

Applies towards:

BK/FL/MJ/ML/WH2012
WH2012A
LF3622-WH
WH2012A-3DLF
FL/MJ/ML/WH2012B

List of Hardware:




- 1.) Install 4 leveling glides. Keep the front two leveling glides 1/4" taller than the back back two, which means your file will be slightly tilted back. This is the proper way to level a lateral file cabinet. It keeps any unlocked file drawers from creeping open and distributes the weight more evenly.
- 2.) Use the screws to attach drawer pulls.

Questions? Please call 1-800-443-5117. Customer Service available 8:30 - 5:00 Central Time, Monday - Friday





5-Shelf Bookcase Assembly Instructions




List of Hardware:



- 1.) Attach Kick Plate to Bottom Shelf using the cam locks and pins. Once connected, twist cam locks with your screwdriver to secure the connection.
- 2.) Next, insert all dowels, cam locks and cam pins into the Back Panel. Attach Middle Fixed Shelf and Bottom Fixed. Shelf with attached Kick Plate.
- 3.) Attach Left & Right Side Panels in same method.
- 4.) Now, insert the four leveling glides into the bottom of the bookcase.
- 5.) Attach the Top Shelf to the rest of the bookcase.
- 6.) With a helper, carefully turn the bookcase upright.

Tools Needed:

- -Phillips Screwdriver -A Helper
- 7.) Insert Shallow & Deep Covers over the cam locks.
- 8.) The last step is to insert the shelf pins into the predriled holes along the inside of of the Left & Right side panels. Then set the adjustable shelves inside.




Questions? Please call 1-800-443-5117. Customer Service available 8:30 - 5:00 Central Time, Monday - Friday



www.modernofficefurniture.com

5-Shelf Bookcase w/Doors Assembly Instructions



List of Hardware:



Tools Needed:

-Phillips Screwdriver -A Helper

- 1.) Attach Kick Plate to Bottom Shelf using the cam locks and pins. Once connected, twist cam locks with your screwdriver to secure the connection.
- 2.) Next, insert all dowels, cam locks and cam pins into the Back Panel. Attach Middle Fixed Shelf and Bottom Fixed. Shelf with attached Kick Plate.
- 3.) Attach Left & Right Side Panels in same method.
- 4.) Now, insert the four leveling glides into the bottom of the bookcase.
- 5.) Attach the Top Shelf to the rest of the bookcase.
- 6.) With a helper, carefully turn the bookcase upright.
- 7.) Attach doors with the hinges provided. You will need to adjust the hinges to level the doors (Figure 2). Attach door pulls with screws provided.
- 8.) Insert Shallow & Deep Covers over the cam locks.
- 9.) The last step is to insert the shelf pins into the predriled holes along the inside of of the Left & Right side panels. Then set the adjustable shelves inside.

