



1.) Attach brackets to underside of chair with the M6x16 Screw, using the Allen wrench.

2.) Set table top on brackets and connect using the same screws.