


Sterling Heavyweight Airport Beam Seating Assembly Instructions

No.	Part	Description	1 Seat	2 Seat	3 Seat	4 Seat	5 Seat
1	J	Seat	1	2	3	4	5
2	T	Seat Bracket (Left)	1	2	3	4	5
3		Seat Bracket (Right)	1	2	3	4	5
4	0	Seat to Bracket Bolt	8	16	24	32	40
5		Beam	1				
6	P	Beam to Bracket Bolt	4	8	12	16	20
7		Feet	4			6	
8	A	Left Leg			1		
9		Right Leg			1		
10	5	Left Arm			1		
11	6	Right Arm	1				
not shown		Center Leg (5-Seat Only)	n/a			1	
12	1	Beam to Leg Bolt	4			6	
Tool	~	Allen Wrench	1				
Tool	0	Allen Wrench Extender			1		

Instructions apply to 1-Seaters, 2-Seaters, 3-Seaters, 4-Seaters and 5-Seaters, although a 3-Seater is illustrated for reference



CustomerSvc@ModernOfficeFurniture.com

8:30AM - 5:00 PM, Central time, Mon-Fri



Fully Upholstered Beam Seating Cushion Installation Guide

EACH SET INCLUDES: 1 BACK CUSHION, 1 SEAT CUSHION, 1 MIDDLE CUSHION AND 12 SELF-DRILLING SCREWS

Side Profile of Seat Cushion Curved on one end only

Back of seat

Front of Seat


Side Profile of Back Cushion Small Curve on one end, Large Curve on other


Lower back

Top of backrest

Step 1) Start with Back Cushions. Use 4 screws to attach the cushion, one screw per corner.







Step 2) Attach Middle Cushion in same method.

Step 3) Turn Beam Seater over to attach the seat cushions.