

(2) Dry fit CHEEKS to TRAIL using GUN BARREL to check alignment. Adjust as needed, then apply glue to SHIMS (discs) on CHEEKS and attach to TRAIL sides.

(3) Install AXLE HOUSING to CHEEK and TRAIL CUT-OUTS. Apply cement in unexposed areas. Align with TRAILS and allow to dry thoroughly. Apply cement to inside of CENTER SHACKLE and drop over AXLE HOUSING with HOOK forward. Apply cement to SIDE SHACKLES and install directly under each CHEEK.

(4) Paint this assembly light gray or olive drab. Paint SCREW HOUSING black.

(5) Paint all remaining parts black, apply cement to inside surfaces and pins and install according to the illustration.

(6) Paint WHEELS light gray or olive drab with bands on hubs and tire bolts black. Slide on WHEELS (narrower hubs out), trim AXLE ends if needed and attach HUB CAPS.

(7) Emplace CANNON on CHEEKS and cement CAP SQUARES to CHEEKS over TRUNION BARS.

(8) Take 3.5" of chain, spread end link and attach on itself 15 links from that end. Likewise attach the other end to the EYE PLATE. Hook the looped end over the LINSTOCK. Cut remaining chain into four l" lengths and attach ends to small pins on CHEEKS and CAP SQUARES as shown.

(9) Spread cast SECURING CHAIN and squeeze into holes in TRAIL. Do not cement, allow to swing freely.

(10) Paint TURNING SPIKE black or dark brown, slip through LEFT SPIKE RING and hang its ring onto HOOK PLATE on LEFT CHEEK.

> (11) Assemble the BUCKETS. WATER BUCKET (tall one) is illustrated. GREASE BUCKET or Similar. Hook WATER BUCKET on CENTER SHACKLE HOOK. GREASE BUCKET hangs from LEFT PITTON hook.

bucket handle to the SECURING CHAIN PITON hook with the ram end through the RAMMER/SPONGE hangs on the right or SPONGE dirty tan; paint the dowels black rings, then through the hanging water SCOOP handles go through the PITON SECURING CHAIN. The WORM and RAMMER HEAD to opposite ends of one (12) Fit the SPONGE HEAD and fashion the WORM (5/32" ID) and insert 1/8" x 4" dowel. Use the provided wire to this into the third dowel. Paint the 1/8" x 4" dowel, the SCOOP to another stain them dark wood. The

(13) Seize an eye in the ends of the provided cordage using the provided thread. Catch an eye on one ROPE CLEAT and loop the cord around both, figure-eight fashion. Catch the second eye on the other CLEAT.

COLORS:

The complete carriage and wheels were painted a light gray or olive drab. The exact color would have varied from gun to gun. Most batteries painted all metal parts black. These parts are marked with an "X" on the illustration. The cast iron gun barrel was also painted black.

This model is derived from the original Marine Model Company kit and has been updated by Model Shipways Inc. and Ken Goldman.



anufactured by Model Shipway A division of Model Expo, Inc. Hollywood, Florida, USA

ww.modelexpo-online.com