



***Biasing Your Amplifier:**

***When Facing the front of your amplifier, Turn the Bias Potentiometer Completely Counter Clock-Wise.**

***Make sure you have a speaker or dummy load connected at all times when your amplifier is powered on.**

***Install Power, Rectifier, & Preamp Tubes**

***Plug in a Shorting Plug to the RCA Input Jack. This is to ensure that if you hear any audible noise when first powering your amplifier on, it is isolated to the amp and is not coming from a noisy source.**

***Power Amplifier On, Slowly Turn Bias Pot Clock-Wise until you get a reading of 1.4V (70mA per tube) on the front Bias Test Point.**