



## **PK-EX4 CATCHER**

### **INSTALLATION DIRECTIONS**

This catcher uses a piece of steel that is approximately 1" tall welded onto the deck directly above the discharge opening and running the length of the discharge opening. This piece of steel is located at the very edge of the deck directly above the discharge opening. It may have a ½" hole in it towards the front of the mower. The catcher has a series of holes above the opening. These holes are where the brackets are to be bolted. The series of holes on the catcher allows you to bolt the brackets wherever you may have to line up the catcher to avoid obstacles such as the deflector ears, ect... Bracket "A" is a big ½" pin that is to be bolted towards the front of the catcher. The big pin ("A") engages the hole in the vertical piece of steel welded to the deck. If there isn't a hole you will have to drill ½" hole into the steel. Bracket "B" is a ramp that is to be bolted towards the rear of the catcher. To mount the catcher onto your mower hold it up at a 45 degree angle with the front of the catcher down and the rear of the catcher up. Insert big pin ("A") into the ½" hole then rotate the rear of the catcher down so the ramp catches that piece of steel. To remove the catcher reverse this procedure. Your installation is now complete.

### **IF INSTALLING**

**PKB-UN BRACKET PLEASE READ THROUGH THE  
DIRECTIONS BELOW.**

# PKB-UN BRACKET

## INSTALLATION DIRECTIONS

This bracket is to be bolted onto the deck above the discharge opening at the very edge. The side with the ½" hole faces up, and the end with the hole should be towards the front of the mower. Now see the PK-E instruction to continue installation. The bracket is used as the 1" tall piece of talked about in the PK-EX4 directions. If you need further assistance please call 570 226-6093 Monday-Friday.