



PK-OB4 CATCHER

INSTALLATION DIRECTIONS

This catcher comes with a bracket that has to be bolted to the mower deck for installation. Leave the bracket on the catcher and hold the entire assembly against the deck where it would belong. (Use 2 people for tighter fit and better installation). It should align itself where it has to go. The Bracket will rest on the deck directly above the discharge opening. Hold everything tight against the deck where you want it and then mark the holes. Drill the deck holes and bolt the bracket on to the deck. Simply insert the catcher mounting pins into the bracket. Your installation is now complete.

IF INSTALLING ON A *Scag Freedom Rider 48", 52" & 61"*.

PLEASE READ AND INSTALL PKB-RAD DEFLECTOR PLATE

FIRST AS DIRECTED BELOW

PKB-RAD DEFLECTOR PLATE

INSTALLATION DIRECTIONS

This bracket is used with a ***Scag Freedom Rider 48", 52" & 61"***. The deflector plate is to be bolted on towards the rear of the discharge opening using the stock hole. This plate makes the discharge opening a little smaller to accommodate the catcher. Continue with the PK-OB4 directions. If you need further assistance please call 570 226-6093 Monday-Friday.