

Pioneer Hard Coat Full Windshield

Fits: 2014 Honda Pioneer

P/N: EMP-12495

Includes:

1. (1) Top Metal Stiffener– Black (12495-02)
2. (1) Hard Coated Windshield (12495-01)
3. (6) “Patent Pending” Rubber Fast Straps (p/n 11651)
4. (6) 1/4-20 x 3/4” Black Truss Head Screws
5. (6) 1/4” Flange Nuts
6. (2) 1/4” x 17-1/2” Edge Trim/Gasket (bubble style)
7. (1) 10-1/2” Long Hood & Loop (Velcro)
8. (1) Logo Sticker



Installation:

1. Peel back the protective film off the top, bottom, and sides exposing the area to install Fast Straps, Stiffener, Velcro, and Edge Trim. The protective film is on both sides. There is **NO RETURNS** after this is peeled back or removed.
2. Bolt the metal stiffener to the top using the (6) 1/4” screws and nuts. The stiffener will go behind the windshield (see fig. 2)
3. Stick the Velcro to the center of the bottom. Stick one side to the hood and one to the windshield so it will not vibrate when installed.
4. Slide the (2) 17-1/2” Strips of edge gasket over the bottom ends of the windshield (see fig. 2). These will protect and seal between your hood and windshield.
5. Bolt the (6) Rubber Fast Straps to the slots along the sides of the windshield using the hardware that is attached to the Fast Straps. **NOTE: Do not tighten the bolts until you install the windshield.** You can adjust the straps in the slots before tightening the bolts.



WWW.EXTREMOMETALPRODUCTS.COM