



## First Team Sports, Inc | FT190 Breakaway

### Installation:

To install the rim you will need the following items.

1. Ratchet w/ 3/8" socket
  2. Ratchet w/ 9/16" socket with extension
  3. Level
- 
1. Remove the goal hardware from the hardware bag furnished with the goal. Slide two carriage head bolts through the top slotted holes in the backplate of the rim with threaded ends protruding out the backside of the goal.
  2. Hold the bolts against the inside of the backplate while positioning the goal on the backboard. Insert the bolts through the holes in the backboard, attach flatwashers, lockwashers and hex nuts. Finger tighten them for now.
  3. Insert bottom two carriage head bolts into place and finger tighten using flatwashers, lockwashers and hex nuts. (Add flatwashers, lockwashers and hex nuts if threaded studs are located at lower attachment points)
  4. Using your level, make sure the rim is level side to side. Finish tightening all four nuts. Tighten nuts evenly. (Use 30 lbs. torque)
  5. Fasten coverplate into position using the two self tapping screws provided and a ratchet with a 3/8" socket. **NEVER USE THE GOAL WITH THE COVERPLATE REMOVED!**
  6. Attach net.