

Arch Mailbox Conversion Kit Installation Instructions

1. Remove existing screws that mount faceplate to your box (Screws are found half way up just on inside of the door on both the left and right side)
2. Open locking door on steel locking insert.
3. Insert door at an angle through the faceplate door into mailbox.
4. Pull locking insert up tight against faceplate with bottom of steel insert resting on masonry can, then insert screw into side of steel insert to fasten to faceplate and masonry can.
5. Insert second screw into opposite side to secure steel insert to faceplate and masonry can. Enjoy.



Custom Home Accessories, Inc
11300 Trade Center Dr., Ste. A
Rancho Cordova, CA 95742
Toll Free: 1-800-265-0041
Phone: 916-635-0231
Fax: 916-635-0228
www.customhomex.com