

Penofin Oil Treatment Instructions

- 1. SHAKE WELL BEFORE USING. DO NOT add thinning or blending agents.
- 2. Apply Penofin to a clean dry surface. Surface must be free of dirt and sawdust build-up. Do not apply when wood is hot to the touch. Minimum temperature is 45 degrees Fahrenheit.
- 3. Brush on, use a stain pad, or spray on using a pump-up sprayer equipped with plastic tip.
- 4. To allow for maximum penetration wait 30 minutes, then use a nap-free shop cloth and wipe the entire surface, removing excess product.
- 5. Surface will be dry to the touch in three hours, and ready for use in 12 hours.
- 6. When using the one-coat formula, the application is now complete.
- 7. Do not apply wet-on-wet. Average coverage needed is 175-300 sq. ft. per gallon.
- 8. If using the two-coat formula, wait a minimum of three hours and apply a light second coat and again wipe any excess from the entire application area after 30 minutes.

<u>NOTE</u>: No stripping or sanding is necessary for maintenance. Just wash the surface with water and a mild detergent. Allow surface to fully dry for approximately 48 hours.

CLEANING: Use paint thinner or mineral spirits to clean up.

CAUTION:

- Combustible keep this product away from heat, open flame, and sparks.
- Beware of spontaneous combustion. Make certain all rags or other materials used with Penofin are soaked in water, stored in an air-tight container, or otherwise disposed of safely.
- Avoid contact with skin and breathing vapor or spray mist. Use only with adequate ventilation. Do not take internally.
- If swallowed, do not induce vomiting. Call a physician immediately.
- Shelf life is limited once factory seal is broken. Secure lid tightly after each use.