

# RA-14 – Basket Kit

## Assembly

1. Insert 4 screws into the holes on the four corners of D and C through each opposite hole on A and B, hand tighten.
2. Insert 8 screws into the holes on the two rims of E through each opposite hole on C and D, hand tighten.
3. Tighten the screws through C, D and A, B, then tighten the screws through E, C and D.

## Installation

1. For 6 1/2' wide open trailers (the most popular) the basket kit will rest on the side rails as is. Mark and drill the holes. Bolt the unit to the rails. The basket also comes with a kit (4 angle iron brackets) which can be bolted to the legs on either the inside or outside to fit trailers that are wider or thinner than 6 1/2'.

Due to the many different ways trailers are built, the hardware required to attach the rack is not included and must be supplied by the user.

**NOTE: It is the buyer's sole responsibility to make sure that the rack is installed safely and securely to a component that will adequately support the equipment.**

