

## 9016 Series Solar Pillar Light Instructions

Thank you for purchasing our 9016 series Solar Pillar Light. They are easy to operate.

Before mounting please set your fixture outside in full Sun for 3 days on the off position to charge the battery. You can choose between 3,000K warm white or 6,000K cool white.

To turn on the fixture locate the toggle switch (pictured below) Center position is off. Left position is warm and right position is cool white. Due to the many surfaces and methods of mounting we do not supply mounting hardware.

It is very important to mount these fixtures in an area that receives full sunlight for at least 8 hours for maximum efficiency.

