

Classy Caps

Lighting Instructions

How Your Solar Powered Post Cap Works

- The solar panel converts sunlight energy into electricity during the day. The Photocell automatically turns the light on at night with the electricity stored in the batteries. It requires no wiring, because it runs off of the sunlight energy to recharge the batteries so there is no cost to run the solar cap.
- The number of hours the light stays on depends on your geographical location, weather conditions and seasonal sunlight availability.
- Easy "Do-it-yourself installation"

Each Classy Cap Includes:

- 1 - solar post cap light
- 2 - #4 mounting screws
- 2 - AA mAh NiCad rechargeable batteries


Post Cap Installation

- 1) Remove plastic tab from battery compartment
- 2) Secure solar fixture to post using two #4 stainless steel mounting screws provided. (pre-drill 5/64" pilot holes into post to easily fasten screws).
You can also apply any outdoor silicone to the bottom inside edge of cap before installation for added security
- 3) Allow at least 8 hours of sunlight to fully charge the batteries.

Note: Classy Caps feature a removable lid to easily replace the batteries (battery replacement is about 2 years).

To Replace The Batteries

- 1) Carefully pull up from all 4 corners of lid (fig. 1).
Replace the batteries with new AA size 1.2V 1200 mAh rechargeable batteries.
Be sure to insert batteries in the proper direction.
- 2) Firmly snap the lid back into place. Be sure that all 4 corners of lid are secured to cap base.
- 3) Allow the fixture to receive a full 8 hours of sunlight to allow the rechargeable batteries to reach maximum capacity.



Troubleshooting

If the light does not turn on at dusk after 8 hours of charging:

- Check the batteries to make sure they are making secure contact with the terminal
- Be sure the solar fixture is in a relatively sunny location.
- Make sure the light's photocell is not affected by other light

Caution

- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause them to explode or leak.
- Do not mix old and new batteries.
- Do not mix Alkaline, Standard (carbon- zinc) or Rechargeable (nickel cadmium) or (nickel metal hydride) batteries.
- Do not dispose of batteries in fire.

Maintenance

Periodically clean light fixture with soft cloth and warm soapy water.

Two Year Limited Warranty

Classy Caps Mfg. Inc. products are warranted to be free from defects in workmanship or materials at the time of purchase for a period of two years, (excluding batteries). Should a defect occur, please contact our customer service line at 1-866-460-4604 for service.

Should any evidence of defects in material or workmanship appear within the warranty period after the date of purchase, Classy caps Mfg. Inc. will either repair or replace the product at its option.

Classy Caps Mfg. Inc. is not responsible for injury, property damage, or other consequential damages or damages to third parties arising directly or indirectly from an actual or alleged defect in material or workmanship of the product.