




41628 FRANCO

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside




04 Home Theater
Ottoman
44 x 28 x 19"
112 x 71 x 48cm



09 Corner Curve
47 x 47 x 40"
119 x 119 x 102cm



10 Armless Chair
23 x 39 x 40"
58 x 99 x 102cm




26 LHF Sofabed 54"
27 RHF Sofabed 54"
71 x 39 x 40"
180 x 99 x 102cm



30 Armless Recliner
60 Power Armless
Recliner
23 x 39 x 40"
58 x 99 x 102cm



32 Rocker Recliner Chair
31 Wallhugger Recliner
Chair Pwr
33 Swivel Rocker
Recliner Chair
35 Wallhugger Recliner
Chair
39 Power Rocker
Recliner
40 x 39 x 40"
102 x 99 x 102cm
IA: 17" / 43cm



Dimensions

A - Seat Depth - 21" / 53cm

B - Seat Height - 20" / 51cm


C - Arm Height - 28" / 71cm

Features


- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Toggle power mechanism



46 RHF Recliner Chair
47 LHF Recliner Chair
66 RHF Power Recliner
67 LHF Power Recliner
33 x 39 x 40"
84 x 99 x 102cm



51 Sofa Recliner
61 Power Sofa Recliner
86 x 39 x 40"
218 x 99 x 102cm
IA: 63" / 160cm



53 Loveseat Recliner
63 Power Loveseat
Recliner
64 x 39 x 40"
163 x 99 x 102cm
IA: 41" / 104cm



86 RHF Seating Wedge
87 LHF Seating Wedge
49 x 39 x 40"
124 x 99 x 102cm



A0 11 Degree Storage
Wedge
17 x 39 x 36"
43 x 99 x 91cm



A1 45 Degree Storage
Wedge
36 x 37 x 36"
91 x 94 x 91cm



A2 Storage Console
13 x 39 x 36"
33 x 99 x 91cm



41628 FRANCO

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty


Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use


Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty




CONFIGURATION MA
105 x 105"
267 x 267cm




CONFIGURATION MB
103 x 120"
262 x 305cm




CONFIGURATION MD
116 x 120"
295 x 305cm




CONFIGURATION ME
163 x 74"
414 x 188cm




CONFIGURATION MF
123 x 68"
312 x 173cm




CONFIGURATION MG
162 x 72"
411 x 183cm



CONFIGURATION MH
115 x 64"
292 x 163cm



CONFIGURATION MI
151 x 64"
384 x 163cm



CONFIGURATION MJ
113 x 113"
287 x 287cm

CONFIGURATION MK
96 x 96"
244 x 244cm