


## **Electric Lift Conference Table Assembly Instructions**




nical data	
Column Stage	3
Max. Weight Capacity	125KG
Height Range	580-1230mm
Width Range	1100-1900mm


#### Accessory list


Attention: The drawings below are for guidance only and they may differ slightly from the product and fittings received. Please contact our customer service department should you have any queries.


No.	Image	Spec	Qty
Α	0	M6	4
В	0	M6	4
С		M6	8
D	0	M6	12
Е	\zmm.	Self-Drilling Wood Screw	16
F		Allen Wrench	1


Separate Pack Labeled METALPLATES4747
ALSO INCLUDED



























Questions? Please call 1-800-443-5117. Customer Service available 8:30 - 5:00 Central Time, Monday - Friday



# **Operating Instructions**



### Introduction to the Buttons:

(1) "▲": Adjust the desk upwards

(2) "▼": Adjust the desk downwards

(3) "1": Position 1, first height position saved by the user

(4) "2": Position 2, second height position saved by the user

(5) "3": Position 3, third height position saved by the user

(6) "M": Height memory function

(7) "A": Alert button to remind users changing posture

## Settings:

Height Adjustable Function:

Press the "▲" or "▼" button to adjust the height. The LED display shows the current height.

Height Memory Function:

a. Press UP or DOWN button and adjust the height to the desired height. Press "M" to save the height, and the screen will display "\( \sigma\_-\)";

Press "1", "2", or "3" then, that is, save the height to the corresponding position 1 or 2 or 3, which will show in the display screen as " $\varsigma_{-}$ ,", " $\varsigma_{-}$ ,", or " $\varsigma_{-}$ ,";

b. Press "1", "2" and "3" button directly to automatically adjust the memory height you saved.