Classy Caps

Lighting Instructions

FIG 1

Auto/off

Spotlight

switch

How Your Solar Powered Spotlight Works

- The solar panel converts sunlight energy into electricity during the day. The photocell automatically turns the light on at night with the electricity stored in the batteries. It requires no wiring, because it runs off the sunlight energy to recharge the batteries so there is no cost to run the solar cap.
- The number of hours the light stays on depends on your geographical location, weather conditions and seasonal sunlight availability.
- · Easy "Do-It Yourself" installation.

Includes

1 – High performance solar spotlight 1 - LiFeP04 3.2V 600 mAh rechargeable battery

Instructions

- 1) Turn the auto/off switch to auto (fig.1)
- 2) Place the fixture in a sunny location and adjustment the angle of the spotlight as desired
- 3) Allow the fixture to receive 24 hours of sunlight (2 days) so the rechargeable battery can reach maximum capacity

Replacing the Battery

For best results the batteries should be replaced every 12 months.

- 1) Turn the auto/off switch to off (fig.1)
- 2) Remove the screws from the bottom of the solar panel and carefully remove the solar lid. Do not disconnect the wires. (fig.1)
- 3) Replace the battery with a new LiFeP04 3,2V 600 mAh rechargeable battery
- 4) Replace the solar panel and turn the auto/ off switch to on
- Allow the fixture to receive 24 hours of sunlight (2 days) so the rechargeable battery can reach maximum capacity

Troubleshooting

If the light does not turn on at dusk after 24 hours of charging:

- Check the batteries to make sure it is making secure contact with the terminal.
- Be sure the solar fixture is in a relatively sunny location.
- Make sure the light's photocell is not affected by other light.

Maintenance

Periodically clean light fixture with soft cloth and warm soapy water.

One Year Limited Warranty

This product is warranted to be free from defects in workmanship or materials at the time of purchase for a period of one year, (excluding batteries). Should a defect occur, please contact our customer service line at 1-866-460-4604 for service. Should any evidence of defects in material or workmanship appear within the warranty period after the date of purchase, Classy Caps Mfg. Inc. will either repair or replace the product at its option. Classy Caps Mfg. Inc. is not responsible for injury, property damage, or other consequential damages or damages to third parties arising directly or indirectly from an actual or alleged defect in material or workmanship of the product.

