

## **Jovision Quick Start Guide**

The default user name and password are “abc” and “123”.

From the main screen on your Jovision unit, right click → Network and locate your CloudSEE id. This is the id you enter on your remote viewing software.

Install the Jovision software on your PC from either the provided disc or download at <http://www.jovision-usa.com/downloads.html>.

In the Jovision JDACS software go to the settings tab on the bottom right and enter your CloudSEE id. Click “apply to all”, “save” and “ok”. On the main menu click “Link All” on the bottom right to view your Jovision DVR.

### **Tips and Trouble Shooting**

-Ensure that the Jovision JDACS software was unzipped before installing.

-On the Jovision Unit ensure these settings are set...

From main menu, right click → System → System → Enable WebServer and Enable Mobile Server are both checked → Save.

From main menu, right click → System → Channel → Set the Rec Mode drop box in upper right to “Net Mode” → NTSC/PAL drop box is set to “NTSC” → “Apply to All” → Save.

-From main menu, right click → System → Users. Make sure that both your Local user and Net user are the same with same password on the admin account to enable to all features. Only admin users can assign other users and have full access to all features.

-USB back up requires that the USB device is at least 2.0 speed and formatted in FAT32.

-It is strongly recommended that you use the Jovision JDACS software instead of ActiveX IE when using Windows Vista or 7.