## CLK1000DXMR-02 **CAN-AM DEFENDER 1000 XMR LIFT KIT**





sales@highlifter.com



800-699-0947 | 8:00am - 5:00pm CST



7455 Atkinson Drive, Shreveport, LA 71129













www.highlifter.com

Parts Available For These Popular Brands and Others











#### PRODUCT DISCLAIMER

The installation of products sold or manufactured by High Lifter Products including, but not limited to suspension components such as lift kits, gear reduction lifts, frame stiffener kits, snorkels, and tires that exceed the original specifications for the vehicle, may change the vehicle's center of gravity and handling characteristics both on- and off-road. You are aware that the installation of tires that are larger than original vehicle specifications may reduce the effectiveness of the braking system. Use of these products may place added stress to the original factory vehicle components which could cause them to weaken or possibly fail.

Products sold or manufactured by High Lifter Products are intended for off-road use only. Operation of a vehicle modified with these products on a road could result in serious bodily injury or death, and such operation may violate the laws of your state or municipality. You agree to operate your vehicle exclusively in the manner intended by the vehicle manufacturer. You agree that failure to safely and reasonably operate your vehicle could result in serious bodily injury or death, and that, as a result of installation of this product(s) to your vehicle, extreme care must be taken to prevent vehicle rollover or loss of control, which may be more likely to occur as a result of said modifications. You will avoid unsafe maneuvers, including sudden sharp turns or other abrupt maneuvers, which could make a vehicular accident more likely. You understand that High Lifter Products is not responsible or liable for any damages or any injuries to yourself or your passengers that could occur upon possible accidents due to driver error, incorrect installations, bad judgment, incompatibility with other aftermarket accessories or natural disasters to the fullest extent allowable by law.

You will have all vehicle occupants fasten seatbelts, if equipped, and wear proper safety equipment, such as DOT approved helmet and eye protection prior to operating the vehicle. You understand and acknowledge that failure to wear proper safety equipment may increase the risk of serious bodily injury or death to yourself and any passengers.

Proper installation of products sold or manufactured by High Lifter Products requires knowledge of the factory recommended procedures for removal and installation of original equipment components. Installation of these products without proper knowledge and experience may affect the performance of these components and the safety of the vehicle and cause serious bodily injury or death. It is strongly recommended that a certified mechanic familiar with the installation of similar components perform the product(s) installation.

Prior to installing any products sold or manufactured by High Lifter Products, you will perform or cause to be performed an inspection of their vehicle to confirm its condition is suitable for the installation of these products. A proper inspection of the vehicle includes confirmation that the vehicle has not been in a collision and is free of corrosion. If the vehicle is suspected to have been in a collision or misused, or is otherwise unsuitable for modification, you will not install the product(s). You will continue to inspect the vehicle prior to each use to confirm its condition is suitable for its intended use, and you acknowledge that the failure to do so may result in serious bodily injury or death, as well as damage to the vehicle itself.

You will install any warning labels provided with the product so it may be prominently seen by yourself and all passengers. You will notify all passengers of the modifications performed to your vehicle prior to operation.

Insurance companies may handle coverage of a modified vehicle differently. Please check with your insurance carrier prior to modifying the vehicle to ensure your coverage remains sufficient.

Installation of this product(s) may void your vehicle warranty. If this is a concern, please check with the manufacturer or dealer before purchase or installation of this product(s).





#### HIGH LIFTER LIMITED LIFETIME WARRANTY

High Lifter offers a Limited Lifetime Warranty to the original purchaser that our product shall be free from defects in material and workmanship for the life of the product if utilized in accordance with the manufacturer's instructions for installation and operation of said products.

#### LIMITED LIFETIME WARRANTY EXTENDS TO THE FOLLOWING PRODUCT LINES:

Lift Kits (Signature, Standard and Big Lifts)

Control Arms

Trailing Arms

Radiator Relocation Kits

Portal Gear Lifts

Wheel Spacers

Tow Hooks

Control Arm Link Kits

Damages to vehicle or any other object during the installation, use, or removal of High Lifter products are not covered under this warranty. Normal wear items included with any of the products covered under this Limited Lifetime Warranty are excluded from coverage. These items include, but are not limited to heim joints, tie rods, bearings, bushings, seals, gaskets, zinc plating, painted and powder coated finishes. Other exclusions of coverage under this warranty include, but are not limited to: damage or product failure due to improper installation, lack of maintenance, product modification, abuse, collision or use on vehicles for which product was not designed, repairs performed by anyone other than approved High Lifter personnel or made using non-High Lifter components. This warranty is valid for the original purchaser only and is non-transferable. High Lifter reserves the right to inspect any product before determining if the claim is valid and covered under this warranty. Claims determined to be caused by reasons other than a manufacturer defect will be rejected and an estimate for repair or cost of a replacement product if a repair is not possible, will be provided.

This warranty is exclusive and is in lieu of any implied warranty of merchantability, fitness for a particular purpose or other warranty of quality, whether express or implied, except the warranty of title.

#### **WARRANTY PROCESSING**

If you suspect your product is defective, **DO NOT** disassemble the product to determine the cause without prior approval as it may void your warranty status. This is especially true with our Portal Gear Lift. To begin the claim process, please e-mail our warranty team at warrantycare@highlifter.com and include the following in the e-mail:

	Your full name, address and contact phone number.
	The year, make and model of your vehicle
п	The part number of the product

The part number of the product

Photos of the product installed, and vehicle product is installed on

Proof of Purchase (Required for all warranty claims and you must be the original purchaser)

Once a claim is created, you will receive a return authorization number (RMA). Write this number on the outside of the box containing your defective product and include it along with your name and contact information inside the box. Product must be returned in the original box or a box of equal strength and packaging. Product sent without an RMA number visible on the outside of the box or sent COD will be refused. Ship your product to the following address:

**High Lifter Products** 

Attn: 7455 Atkinson Drive. Shreveport, LA 71129

Once your product is received, we often have your replacement or repaired product shipped back to you within 3-business days of receiving it. Please note that High Lifter is not responsible for shipping charges on product returned for warranty or repair, including duties and fees required by those residing outside the United States.



# **PARTS**



58Z REAR SPRING SPACER 73-11949 QTY: 2



80P FRONT SPRING SPACER 73-12736 QTY: 2



REAR LIFT BRACKET 79-16139 QTY: 4

10MM X 60MM BOLT 54- 60952 QTY:6



10MM NUT 54-61038 QTY:6




10MM WASHER 54-61026 QTY:8



0

4Y SPACER 73-11780 QTY:2



STEP 1 SETUP

PLACE JACK UNDER THE MACHINE AND LIFT UNTIL THE WHEELS ARE OFF THE GROUND. BE CAREFUL TO SECURE PROPERLY SO IT IS STABLE ON THE JACK OR JACKSTANDS.

REMOVE WHEELS.

NOTE: IMAGES SHOWN IN THESE INSTRUCTIONS MAY VARY SLIGHTY DEPENDING ON THE MODEL.

#### STEP 2

#### **REMOVE SHOCKS - INSTALL FRONT SPACERS**

DISCONNECT AND REMOVE THE SHOCK.

SPRING SPACER INSTALLATION: (YOU WILL ALSO USE THESE SAME STEPS FOR THE REAR SPRING SPACER INSTALLATION)

FOR THE NEXT STEP YOU WILL NEED A SPRING COMPRESSOR!!! YOU CANNOT INSTALL THE SPRING SPACERS WITHOUT A SPRING COMPRESSOR.

PLACE THE SHOCK IN THE COMPRESSOR OR ATTACH THE COMPRESSOR SO THAT YOU CAN COMPRESS THE SPRING AND REMOVE THE RETAINING CLIP THAT HOLDS THE SPRINGS IN PLACE.

REMOVE THE CLIP.





SLIDE THE SPRING LIFT BRACKET (80P) ONTO THE SHOCK.





PLACE THE SPRING BACK ON THE SHOCK.







COMPRESS THE SPRING AND PLACE RETAINING CLIP BACK ON THE SHOCK.

ATTACH EACH SHOCK BACK TO THE UTV.



## STEP 3 REMOVE REAR SHOCKS AND INSTALL REAR SPACERS

DISCONNECT AND REMOVE THE SHOCKS.

SPRING SPACER INSTALLATION: REPEAT THE SAME STEPS
FROM THE FRONT INSTALLATION TO INSTALL THE REAR SPRING
SPACERS (58Z)

## STEP 4

## INSTALL REAR LIFT BRACKETS

WHEN INSTALLING THE REAR LIFT BRACKETS MAKE SURE TO NOTE THE DIRECTION OF THE BRACKETS.







PLACE A REAR LIFT BRACKET (73V) ON THE OUTSIDE OF THE OUTER SHOCK MOUNT TAB. INSERT A (10MMX60MM BOLT) THROUGH THE BRACKET AND INTO THE SHOCK MOUNT TAB. PLACE THE SPACER (4Y) BETWEEN THE SHOCK MOUNT TABS AND PUSH THE BOLT ALL THE WAY THROUGH.

PLACE ANOTHER LIFT BRACKET (73V) ON THE OUTSIDE OF THE INNER SHOCK TAB AND SLIDE THE BOLT THROUGH. ATTACH WITH A (10MM LOCK NUT).





AT THE LOWER BRACKET HOLES. PLACE THE SPACER (4X) BETWEEN THE SHOCK MOUNT TABS AND PUSH A (10MMX60 BOLT) ALL THE WAY THROUGH THE SHOCK TAB AND OTHER LIFT BRACKET. ATTACH WITH A (10MM LOCK NUT).







LET THE SHOCK DOWN TO RESTING POSITION. INSERT ONE (10X60MM HEX BOLT) THROUGH THE UPPER BRACKET HOLE. THEN PLACE TWO (10MM FLAT WASHERS) BETWEEN THE SHOCK EYE AND OUTER BRACKET. INSERT THE BOLT THROUGH THE BRACKET AND INTO THE SHOCK EYE.



PLACE TWO (10MM FLAT WASHERS) BETWEEN THE SHOCK EYE AND INNER BRACKET. SLIDE THE BOLT ALL THE WAY THROUGH AND ATTACH WITH A (10MM LOCK NUT).







#### REPEAT STEPS FOR THE OPPOSITE SIDE.



PLACE WHEELS BACK ON THE UTV AND TORQUE LUGS TO FACTORY SPECIFICATIONS.

INFO ABOUT TORQUE SPECS CAN BE FOUND AT THE END OF THESE INSTRUCTIONS.



TORQUE-TENSION RELATIONSHIP FOR A307A, GRADE 5 & 8

THE TORQUE VALUES **CAN ONLY BE ACHIEVED IF THE NUT** (OR TAPPED HOLE) HAS A PROOF LOAD **GREATHER THAN OR EQUAL TO THE BOLTS** MINIMUM ULTIMATE **TENSILE STRENGTH. CLAMP LOAD IS CALCU-LATED AS 75% OF THE PROOF LOAD WHEN SPECIFIED BY THE** STANDARD. ASTM A307 UTILIZED 75% OF 36,000 PSI.

TORQUE VALUES FOR 1/4 AND 5/16 IN SERIES ARE IN INCH POUNDS.

ALL OTHERS ARE IN FOOT-POUNDS.

(in.) INCH AREA (Sq. in.)	RADE 8									
CLAMP TIGHTENING TORQUE CLAMP TIGH		SAE J429 - GRADE 8								
LOAD LOAD	TENING TO	RQUE								
(lbs.) K=0.15 K=0.17 K=0.20 (lbs.) K=0.15	K=0.17	K=0.20								
UNIFIED COARSE THREAD SERIES										
1/4 20 0.0318 2029 76 in-lbs 86 in-lbs 101 in-lbs 2864 107 in-lbs	122 in-lbs	143 in-lbs								
5/16         18         0.0524         3342         157         178         209         4719         221	251	295								
3/8 16 0.0775 4940 23 ft-lbs 26 ft-lbs 31 ft-lbs 6974 33 ft-lbs	37 ft-lbs	44 ft-lbs								
7/16         14         0.1063         6777         37         42         49         9568         52	59	70								
1/2         13         0.1419         9046         57         64         75         12771         80	90	106								
9/16         12         0.1819         11599         82         92         109         16375         115	130	154								
5/8         11         0.2260         14408         113         128         150         20340         159	180	212								
3/4         10         0.3345         21322         200         227         267         30101         282	320	376								
7/8         9         0.4617         29436         322         365         429         41556         455	515	606								
1 8 0.6057 <b>38616</b> 483 547 644 <b>54517</b> 681	772	909								
<b>1-1/4</b> 7 0.9691 <b>53786</b> 840 952 1121 <b>87220</b> 1363	1545	1817								
<b>1-1/2</b> 6 14053 <b>77991</b> 1462 1657 1950 <b>126473</b> 2371	2688	3162								
FINE THREAD SERIES										
1/4 28 0.0364 2319 87 in-lbs 99 in-lbs 116 in-lbs 3274 123 in-lbs	139 in-lbs	164 in-lbs								
5/16         24         0.0581         3702         174         197         231         5226         245	278	327								
3/8 24 0.0878 5599 26 ft-lbs 30 ft-lbs 35 ft-lbs 7905 37 ft-lbs	42 ft-lbs	49 ft-lbs								
7/16         20         0.1187         7568         41         47         55         10684         58	66	78								
1/2         20         0.1600         10197         64         72         85         14396         90	102	120								
9/16 18 0.2030 12940 91 103 121 18268 128	146	171								
5/8         18         0.2560         16317         127         144         170         23036         180	204	240								
3/4         16         0.3730         23776         223         253         297         33566         315	357	420								
7/8         14         0.5095         32479         355         403         474         45853         502	568	669								
1 14 0.6799 43343 542 614 722 61190 765	867	1020								
10 10 1070 1070 1077	1710	2012								
1-1/4 12 1.0729 59548 930 1055 1241 96565 1509		+								

TABALLE	TENCION	DEL	ATIONCHID	FAD	BALTDIO	FACTEMENC
IUKUUL	·IENZIUN	KEL	ALIUNSHIP	TUK	WEIKIL	<b>FASTENERS</b>

NOMINAL DIA. (in.)	PITCH	(8.8) C	LASS 8.8			10.9 CLASS 10.9				12.9 CLASS 12.9			
		CLAMP TIGHTENING TORQUE			CLAMP	TIGH	TIGHTENING TORQUE			CLAMP TIGHTENING TORQUE			
		LOAD (lbs.)	LUBRICATED (ft-lbs)	ZINC PLATED (ft-lbs)	PLAIN&DRY (ft-lbs)	LOAD (lbs.)	LUBRICATED (ft-lbs)	ZINC PLATED (ft-lbs)	PLAIN&DRY (ft-lbs)	LOAD (lbs.)	LUBRICATED (ft-lbs)	AS RECIEVED (ft-lbs)	PLAIN&DRY (ft-lbs)
4	0.7	858	1.7	1.9	2.3	1228	2.4	2.7	3.2	1436	2.8	3.2	3.8
5	0.8	1387	3.4	3.9	4.5	1985	4.9	5.5	6.5	2319	5.7	6.5	7.5
6	1	1968	5.8	6.6	7.7	2816	8.3	9.4	11.1	3291	9.7	11.0	13.0
7	1	2822	9.7	11.0	13.0	4039	13.9	15.8	18.5	4720	16.3	18.4	21.7
8	1.25	3580	14.1	16.0	18.8	5123	20.2	22.9	26.9	5987	23.6	26.7	31.4
10	1.5	5671	27.9	31.6	37.2	8115	39.9	45.2	53.2	9484	46.7	52.9	62.2
12	1.75	8240	48.7	55.1	64.9	11792	69.6	78.9	92.8	13781	81.4	92.2	108.5
14	2	11289	77.8	88.1	103.7	16154	111.3	126.1	148.4	18879	130.0	147.4	173.4
16	2	15320	121	137	161	21924	173	196	230	25622	202	229	269
18	2.5	18822	167	189	222	26934	239	270	318	31477	279	316	372
20	2.5	23938	236	267	314	34256	337	382	449	40034	394	446	525
22	2.5	29669	321	364	428	42457	460	521	613	49619	537	609	716
24	3	34471	407	461	543	49329	582	660	777	57649	681	771	908
27	3	44924	597	676	796	64288	854	968	1139	75132	998	1131	1331
30	3.5	54819	809	917	1079	78448	1158	1312	1544	91680	1353	1534	1804
33	3.5	67821	1101	1248	1468	97055	1576	1786	2101	113425	1842	2087	2455
36	4	79866	1415	1603	1886	114291	2024	2294	2699	133569	2366	2681	3154

TORQUE VALUES CALCULATED FROM FORMULA T=KDF:

**K=0.15 FOR "LUBRICATED" CONDITIONS** 

K= 0.17 FOR ZINC PLATED AND DRY CONDITIONS, ALSO THE USE OF VARIOUS FORMS OF THREAD LOCKERS HAVE A SIMILAR K VALUE K=0.20 FOR PLAIN DRY CONDITIONS

**D= NOMINAL DIAMETER** 

F=CLAMP LOAD

NOTE: WHEN USING ZINC PLATED (LUBRICATED WITH WAX) TOP LOCK NUTS, THE K VALUE CAN VARY FROM 0.12 TO 0.16.

CAUTION: ALL MATERIAL INCLUDED IN THESE CHARTS IS ADVISORY ONLY. EXTREME CAUTION SHOULD BE USED WHEN USING A FORMULA FOR TORQUE/TENSION REALATIONSHIPS. TORQUE IS ONLY AN INDIRECT INDICATION OF TENSION. UNDER/OVER TIGHTENING OF FASTENERS CAN RESULT IN COSTLY EQUIPMENT FAILURE OR PERSONAL INJURY.