

Comprehensive TIPM Replacement and Reset Guide

1. **Disconnect the Battery**
 - o Disconnect the **negative terminal** from the battery first.
 - o Then, disconnect the **positive terminal**.
2. **Install the TIPM**
 - o Insert the TIPM into its slot.
 - o Ensure all connectors are **firmly and securely inserted**.
3. **Reconnect the Battery**
 - o Reconnect the **positive terminal** first.
 - o Then, reconnect the **negative terminal**.

Your TIPM is now installed. Follow the **TIPM Reset Procedure** to complete the process and ensure proper operation.

TIPM Reset Procedure

For Vehicles with a Push-Start Button:

1. **Enter the "Run" Position**
 - o Press the Start button **twice** without pressing the brake pedal.
 - o This puts the vehicle in "Run" mode (like turning a key to "On").
2. **Wait 2 Minutes**
 - o Allow the TIPM to reset and communicate with the vehicle systems.
3. **Turn Off the Vehicle**
 - o Press the Start button again to shut everything down.
4. **Start the Vehicle**
 - o Press the Start button while holding the brake pedal to start the engine.
5. **Repeat if Needed**
 - o If dashboard warnings or other issues persist, repeat the process.

For Vehicles with a Key:

1. **Enter the "On" Position**
 - o Turn the key to "On" (just short of cranking the engine).
 - o Do not start the engine.
2. **Wait 2 Minutes**
 - o Allow the TIPM to reset and reinitialize vehicle systems.
3. **Turn Off the Vehicle**
 - o Turn the key to "Off" and remove it.
4. **Start the Vehicle**
 - o Insert the key and turn it to "Start" to start the engine.
5. **Repeat if Needed**
 - o If issues continue, repeat the process.