




# Master TOSS BACK<sup>®</sup> Assembly Manual




PLEASE FOLLOW STEP-BY-STEP INSTRUCTIONS  
FOR SUCCESSFUL SET-UP AND OPERATION

Remove and unpack all parts. Use illustrations  
on pages 1 and 2 to identify all parts.




**\*IMPORTANT NOTE:**  
All 4 vertical legs are different.  
Please use illustrations to identify proper parts.




STEP 1: Assemble the left and right side components as shown.


Left side components



Right side components




STEP 2: Slide the left and right sides together around the cross tubes.





## STEP 5. Assemble the net.

Stretch the net with 22 elastic straps around the perimeter of the frame as shown. Use the illustration as a guide for the placement of each strap.



## Master Tossback ready for play





Tel: 1-800-325-2682 Fax: (314) 421-6014  
[www.garedsports.com](http://www.garedsports.com) E-mail: [info@garedsports.com](mailto:info@garedsports.com)