




Playmaker TOSS BACK[®] Assembly Manual




PLEASE FOLLOW STEP-BY-STEP INSTRUCTIONS
FOR SUCCESSFUL SET-UP AND OPERATION


Remove and unpack all parts. Use illustrations
on pages 1 and 2 to identify all parts.




Unpack parts (continued)



STEP 1: Assemble cross tubes to complete base as shown.




STEP 2: Assemble the net frame.




STEP 4. Assemble the net.


Stretch the net with 22 bungee straps around the perimeter of the frame as shown. Use the illustration as a guide for the placement of each strap.




Bungee detail
(Enlarged view)



Playmaker Tossback ready for play





GARED SPORTS

Tel: 1-800-325-2682 Fax: (314) 421-6014
www.garedsports.com E-mail: info@garedsports.com