





What do the LEDs on the ADC-V530 mean?

LED reference guide

LED pattern	Description
Off 	Power off
Solid green 	Connected to Alarm.com
Blinking green 	Local network connection
Blinking red and green 	Reverting to factory default settings
Blinking red 	Power on, camera booting

LED pattern	Description
<p data-bbox="120 260 228 289">Solid red</p> 	<p data-bbox="824 310 1187 340">No local or Internet connection</p>
<p data-bbox="120 491 272 520">Blinking blue</p> 	<p data-bbox="824 541 1247 571">Wi-Fi Protected Setup (WPS) mode</p>
<p data-bbox="120 722 285 751">Blinking white</p> 	<p data-bbox="824 772 1117 802">Access Point (AP) mode</p>