

---

## Adjust the active Wi-Fi band for the ADC-VDB770

The ADC-VDB770's active Wi-Fi bands (i.e., 2.4GHz, 5GHz, or both) are configurable using the MobileTech app.

### To adjust the active Wi-Fi band using the MobileTech app:

**Caution:** Disabling a wireless band that the ADC-VDB770 is already connected to may cause the device to disconnect from the network. Reconnecting the ADC-VDB770 to the network requires physical access to the device.

1. Log into the MobileTech app.
2. Find the customer account.
3. Tap **Equipment**.
4. In *Video Devices*, tap the desired video device.
5. Tap **Configure Video Device**.
6. Tap **Configure Wireless Network**.
7. Tap **Select active wireless bands**.
8. Tap to select the desired bands.
9. Tap **Apply settings to video device**.

