
What do the LEDs on the ADC-VDB775 mean?

LED status guide

LED pattern	Description
Off	Power off
Solid green	Connected to Alarm.com
Blinking green	Local network connection
Blinking red	Power on, camera booting
Solid red	No local or internet connection



LED pattern

Description

Blinking white



Wi-Fi Access Point mode (press and hold the reset button for 30-35 seconds)

Blinking blue



WPS mode (press and hold button for 35-40 seconds)

Blinking yellow



Power cycling (press and hold button for 40-45 seconds)

Blinking red and green



Camera resetting to factory default (press and hold button for 45-50 seconds)

Blinking blue and green



Firmware updating