How often does Alarm.com check the connectivity of the video cameras?

Video camera connectivity is verified every 8 hours. When the video device does not respond to two consecutive pings, a notification/trouble condition is triggered. If there is one *remote access test passed* notification between failures, the count restarts.

For more information, see Video Device - Not Responding.