
Export video using the ADC-CSVR2000P/2008P/2016P local interface

The ADC-CSVR2000P/2008P/2016P allows the user to export video clips using its local interface.

To export video using the ADC-CSVR2000P/2008P/2016P's local interface:

1. Verify a third-party storage device (e.g., flash drive or external hard drive) is inserted into the device.
2. Log into the device's local interface. For more information
3. Click **Search**.
4. Click the desired camera to add it to the screen.
5. Click the desired camera's playback. A blue outline around the playback indicates it is selected.
6. Click **Export**.
7. Click one of the following export options:

Video clip[^]

Saves a video clip from the selected camera to a third-party storage device as an .mp4 file.

1. Set the desired clip length. 1 hour (3,600 seconds) maximum.
2. Using the *Video Quality* slider, select the desired quality.
3. Click to select **Display date/time on video** if desired.
4. Select the destination to begin the export.

Snapshot[^]

Takes a still image from the selected camera and saves it to a third-party storage device as a .jpeg file.

- Select the destination to begin the export.

Archive[^]

Archive footage from the desired cameras.

1. Select all of the desired cameras.



2. Click **Next**.
3. Select the start and end date of the footage to be archived.
4. Select the third-party storage device.
5. Enter the desired file name.
6. Click **Export**.

