

Automatically powercycle PoE ports for offline devices on a Pro Series CSV

On compatible Commercial Stream Video Recorders (i.e., ADC-CSV2008P, ADC-CSV2016P, ADC-CSV2108P, and ADC-CSV2116P), PoE ports can be enabled to automatically powercycle devices that are offline.

To enable automatic powercycling of PoE ports for offline devices:

1. Log in to the Customer website.
2. Click **Video**.
3. Click **Settings**.
4. Select the desired CSV.
5. Click **General**.
6. Click the *Automatically powercycle PoE ports for offline devices* toggle switch.
 - When enabled, the CSV will power cycle the PoE port of any camera that falls offline in an effort to restore the camera's connectivity.
7. Click **Save**.