

How does the Alarm.com Fire Communicator (ADC-FC100) get power?

To be in accordance with the UL Certifications, the Alarm.com Fire Communicator will receive power from the Fire Alarm Control Panel only.