

What do SW1, SW2, and SW3 do on the Alarm.com Fire Communicator (ADC-FC100)?

SW1 and SW2 are currently not used and reserved for future use.

SW3 will toggle on and off remote programming capabilities for the FC100. For more information, see [Remote programming of the communicator is blocked by a local communicator setting](#).