








What do the LEDs on the ADC-V515 mean?

Important: The product or feature described on this page has not yet been released.

For more information about upcoming or newly released products and features, please see [Release Notes on the Partner Portal](#).

LED guide

LED status


| LED pattern | Description |
|---|--------------------------|
|  Off | Power off |
|  Solid green | Connected to Alarm.com |
|  Blinking green | Local network connection |
|  Blinking red | Power on, camera booting |
|  Blinking blue | WPS mode |




LED pattern**Description**

| | |
|---|-------------------------|
|  Blinking white | Wi-Fi Access Point mode |
|---|-------------------------|

Trouble condition**LED pattern****Description**

| | |
|--|---------------------------------|
|  Solid red | No local or Internet connection |
|--|---------------------------------|

Factory reset**LED pattern****Description**

| | |
|--|---------------------------------------|
|  Blinking green and red | Reverting to factory default settings |
|--|---------------------------------------|

