

Update the firmware on an ADC-VC736

To update the firmware using the Dealer Website:

- 1. Log into the Dealer Website.
- 2. Find the customer account.
- 3. Click Equipment.
- 4. Click Video Devices.
- 5. Using the Video Device dropdown menu, select a video device.
- 6. Next to Device Firmware, click Upgrade.

To update the firmware using the Customer Website:

- 1. Log into the Customer Website.
- 2. Click Video.
- 3. Click Settings.
- 4. Using the Video Device dropdown menu, select a video device.
- 5. Click Video Device Info.
- 6. Click Update Firmware.

