

## **Product Description**

Vibra-Tite 642 Cyanoacrylate Remover is a solvent designed to remove cured cyanoacrylate from surfaces. Vibra-Tite 642 can be used to de-bond parts assembled with cyanoacrylates.

## **Typical Applications**

- Cleaning spilled cyanoacrylate off a wide variety of surfaces.
- Removing blooming from parts.

## **Properties of Uncured Material**

|               |                                |
|---------------|--------------------------------|
| Technology    | Solvent cleaner                |
| Chemical Type | Nitromethane / hydrocarbon     |
| Appearance    | Clear to yellow                |
| Viscosity     | Very low                       |
| Cure          | Not applicable                 |
| Application   | Removal of cured cyanoacrylate |

## **Procedure for Application**

1. Product is normally hand applied from the bottle by brushing, wiping or spraying onto parts.
2. Apply Vibra-Tite 642 to cured cyanoacrylate and allow to set until superglue is softened (Typically 2 to 10 minutes). The length of time for cyanoacrylate removal will depend on the thickness of the cyanoacrylate required to be removed.
3. Thin layers of cyanoacrylates may be removed with a Vibra-Tite 642 soaked cloth.
4. Bonded parts may require several hours of soaking to soften the cyanoacrylate.

## **Technical Features**

|                           |           |
|---------------------------|-----------|
| Specific Gravity @ 25°C   | 1.1       |
| Viscosity (cPs)           | 1.5       |
| Shelf Life @ 68°F (years) | 2         |
| Flammability              | Yes, High |

## **General Information**

### **Storage**

Storage: Keep products in the unopened container in a cool and dry location. Ideal storage temperature is between 2°C and 8°C. Temperatures below 2°C can adversely affect product properties. Do Not Freeze. Keep container tightly closed until ready for use. The Shelf-life is 2 years from date of manufacture.

### **Note**

Handling: Material removed from containers may be contaminated during use. Do not pour back any product to the original container. Misuse of product will void all warranties.

## **Health & Safety in use**

Use in a well-ventilated area and read SDS.