
Adjust the chime type for the ADC-VDB770

Configure the ADC-VDB770 chime type to match the chime connected to the device. There is an option to select no chime.

Note: On firmware version 2052+, the chime type can be selected during AP mode Wi-Fi setup. If the option does not appear during AP mode, adjust the chime type after enrollment. For more information about AP mode, see [Alarm.com Video Doorbell \(ADC-VDB770\) - Installation Guide](#).

To adjust the chime type using the Partner Portal:

1. Log into the Partner Portal.
2. Find the customer account.
3. Click **Equipment**.
4. Click **Video Devices**.
5. Using the *Video Device* dropdown menu, select the desired video device.
6. Using the *Chime Type* dropdown menu, select the appropriate chime.

To adjust the chime type using the Customer Website:

1. Log into the Customer Website.
2. Click **Video**.
3. Click **Settings**.
4. Using the *Video Device* dropdown menu, select the desired video device.
5. Click **Video Device Info**.
6. Using the *Chime Type* dropdown menu, select the appropriate chime type. For more information about identifying what type of chime the ADC-VDB770 is connected to, see [What types of chimes are compatible with the ADC-VDB770?](#)
7. Click **Save**.

To adjust the chime type using the Customer app:

1. Log into the Customer app.
2. Tap ☰.
3. Tap **Doorbell Camera**.
4. Tap ⚙️.



5. Using the *Chime Type* dropdown menu, select the appropriate chime type. For more information about identifying what type of chime the ADC-VDB770 is connected to, see [What types of chimes are compatible with the ADC-VDB770?](#)
6. Tap ✓.

