

# Slim Line Doorbell Camera

## LED and Troubleshooting Reference Guide



### LED Pattern Key



### Normal Operation



Ready and working normally

*Use the Alarm.com app or Customer Website to choose a custom color in place of default green.*



In Call mode

*A call has been initiated or is occurring.*



Starting up

*Please wait while the doorbell is booting up.*



Battery is charging

*Battery may charge for ~30 minutes after installation.*



Connected to Wi-Fi, waiting for server connection

*Please wait.*



Firmware update in progress

*Please wait.*

### Requires Attention



No Wi-Fi connectivity

*Check your Internet connection. Your Wi-Fi credentials may have changed. Enter Wi-Fi Access Point Mode (see Troubleshooting below) and re-add the doorbell camera using the app.*



Power supply issue

*Contact your installer. The doorbell transformer may need to be replaced.*

### Troubleshooting

Press and hold doorbell button for the time shown to perform a troubleshooting step.



Entering Troubleshooting modes

*Continue to press & hold for troubleshooting steps below.*



Wi-Fi Access Point mode

*Connect to the camera's temporary network and use the app to re-add the camera. **Push & hold ~60 sec until flashing, then release.***



Power cycle

*Reboots the camera. **Push & hold ~70 sec until flashing, then release.***



Factory reset

*Factory resets the camera. Deletes all Wi-Fi and configuration information. **Push & hold ~80 sec until flashing, then release.***