



## Electric Lift Desk Shell Assembly Instructions



Applies to: (BK/CH/MJ/ML/MWAL/WH) 2001/2002/2043/2089/3624/7124 & ET-223 Electric Lift Base

### List of Hardware:




Tools Needed:

- -Phillips Screwdriver
- A helper!

## Part 1: Desk Shell Assembly

- 1.) Assemble on carpet or cardboard to protect parts during assembly. Assembly will require 2 people for safety.
- 2.) Locate left & right side panels.
  Screw in the leveling glides by hand.
  Then, insert wood dowels & cam pins.
  The wood dowels fit into the slightly larger holes, compared to the cam pin holes



4.) Set the Desktop aside for final install once Electric Lift Frame has been assembled.


See next page for electric lift frame assembly.

Questions? Please call 1-800-443-5117. Customer Service available 8:30 - 5:00 Central Time, Monday - Friday



## Item No.: ET223-BLACK

Installation guide





hı	nical data	$\geqslant$
	Column Stage	3
	Max. Weight Capacity	125KG
	Height Range	580-1230mm
	Width Range	1100-1900mm


### Accessory list


Attention: The drawings below are for guidance only and they may differ slightly from the product and fittings received. Please contact our customer service department should you have any queries.


No.	Image	Spec	Qty
Α	<b>©</b>	M6	4
В	<b>(</b>	M6	4
С		M6	8
D		М6	12
Е	<b>©</b>	St4.2	16
F		Allen Key 4x4mm	1




















### Common fault treatment

The following tips will help you detected and eliminate the common fault and error. If the fault you met is not listed below, please contact with your supplier. Only themanufacturer and professionals are capable for investigating and correcting those fault and error.

Fault phenomenon	Method
No response while long pressing down arrow after connected with	1. Check if all the cables be connected well
a power supply	2. Contact your supplier or dealer
No response while pressing up arrow/ down arrow after connected with a power supply	1. Check if all the cables be connected well
	2. Contact your supplier or dealer
	Check if overloaded, max loading: 125kg;
Rising in a low speed	2. Contact your supplier or dealer
The motor not move as instructed	Contact your supplier or dealer
Go down but not go up	1.Reposition
	2.Contact your supplier or dealer
Danis and all diam	Check if overloaded, max loading: 125kg;
Downward sliding	Contact your supplier or dealer
Frequently Reposition	Check if overloaded, max loading: 125kg;
	Contact your supplier or dealer
Overwork (Duty cycle: Max 2min on/18min OFF)	Restart after suspend for 18mins while connecting with power;
	2. Contact your supplier or dealer;
Not enough up&down height	Press "M"and "3" together for 3 seconds or more, after hearing continuous beeping for twice it will restore factory settings
	2. Contact your supplier or dealer

## Attention

- 1. Power supply: AC100V-240V,50/60Hz
- 2. Service Environment: 0-40°C
- 3. Unplug the power plug before cleaning, wipe the dust on surface with slight wet Origing the power judgment elements, when the data of standard with singlinited dishcloth when cleaning, be careful not to let the drops into the internal parts, not loose the connector.

   The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the

- dispose of it in accordance with each country's environmental legislation, not the general household waste.

  5. Check carefully to ensure can do make less essembly before using.

  5. Check carefully to ensure can do make less essembly before using.

  7. Children are forbidden to play on the product because of unforeseen action when on playing, so any dangerous consequences caused by this improper action will not be not 8. Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment.

  9. Corrosive or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will not pollute the environment.
- of the ceater used in loc pointed me environment.

  10. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play
- appliance in a safe way and understand the hazards involved. Children shall not play with the appliance shall not be made by phildren without supervision. 

  12. If the surply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified present on order to avoid a hazard. 

  13. Please make sure there is no hazard sources in your operating environment, e.g., on not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g., plastic bag may lead to choking hazard to children. 

  14. Keep the original package of the equipment if necessary in case of the future use in the equipment in the cessary in case of the future use in the future was in the surplement in excessing in case of the future use in the future was in the future to the future use in the future was in the future to the future use in the future was in the description of the distribution of the future use in the future was in the future to the future use in the future was in the future to the future use in the future was in the future to the future use in the future was in the future to the future use in the future was in the future to the future use in the future was in the future to the future use in the future was in the future to the future was in the future to the future was in the future was an expectation of the future was in the future was an expectation of the future was in the future was an expectation of the future was in the future was an expectation of the future was in the future was an expectation of the future was in the future was a



This marking indicates that this product should not be disposed with other household wastes.


To prevent possible harm to the environment or human health from uncontrolled waste disposal recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Questions? Please call 1-800-443-5117. Customer Service available 8:30 - 5:00 Central Time, Monday - Friday

# Item No.: HS11A-1

Operation Instruction

# 1. Product Outline



# 2. Product Specification

# Introduction to the Buttons:

- (1) "▲" : Adjust the desk upwards
- (2) "▼" : Adjust the desk downwards
- (3) "1" : Position 1, first height position saved by the user
- (4) "2" : Position 2, second height position saved by the user
  - (5) "3": Position 3, third height position saved by the user
    - (6) "M" : Height memory function
- (7) "A": Alert button to remind users changing posture

# 3. Operating Instructions

- Height Adjustable Function:
- Press the"▲" or "▼" button to adjust the height. The LED display shows the current
- Height Memory Function:
- a. Press UP or DOWN button and adjust the height to the desired height. Press "M" to save the height, and the screen will display "5-";
- Press "1", "2", or "3" then, that is, save the height to the corresponding position 1 or 2 or 3, which will show in the display screen as "5-1", "5-2", or "5-3";
  - b. Press "1", "2" and "3" button directly to automatically adjust the memory height you