

Instructions for Installation of Snappy Pads

For replacement use: Remove the old pad and push the replacement pad securely into place.

For conversion use: Remove all lenses.

1. For any zyl frame select the appropriate size pad;
 - A. FR-6210-small-12mm-works best for children's frames.
 - B. FR-6123-regular-16mm-suitable for women's and most men's frames.
 - C. FR-6238-large-18mm-fits large sunglasses and larger men's frames.
2. Choose the corresponding size template.
3. Position the template on the frames and mark holes.
4. Using a pin vise, hand drill, or power drill, drill the two marked holes using the specially selected drill bit included.
5. Push the pad base securely into the drilled holes.

Additional Pads, 5 pairs per package, may be ordered.