


TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com


Note: Wear eye protection for safety.
Form 5339INST 051031

TRAXXAS TUBES™

Threaded Steel Inserts

Covers Part #5339

Apply blue thread locking compound to the threads before installing the insert into the end of the Tubes. Insert a 2mm hex wrench in the cross-hole of the insert and use a 7mm flat wrench on the hex portion of the Tube to tighten. Do not over tighten.



www.traxxas.com
1-888-TRAXXAS, e-mail: support@Traxxas.com

Note: Wear eye protection for safety.
Form 5339INST 051031