





Every NuFACE device is manufactured in San Diego, California so transit time may vary depending on your location. During transit, the battery of your NuFACE Trinity Device may deplete, which may require a simple reset. Follow these easy steps to get your device charging in no time! Remember, charge your device for 12 hours before first use!



To reset the device, first remove the Trinity Facial Trainer (microcurrent) attachment by pressing the release button and lifting the attachment off.

Obtain a paper clip and bend it as shown. Locate the reset hole to the right of the white serial number label on the top of the device.



Place the device in the charging stand. Make sure it is fully seated. Also, make sure the charging stand is plugged in. Insert the paper clip into the reset hole as shown until it stops. It is not necessary to apply any downward pressure. After making contact and resetting the device, one or more LEDs will flash three times. This will be followed by two power-up tones. The increasing sequential LED pattern will then start, indicating that the charging has begun. Leave the device in the charging stand for at least 12 hours. The reset must be administered with the device seated in its charging cradle for it to be effective.

