# User Manual

RKP215 / 217 / 219
2U 15" / 17" / 19" Rackmount
TFT LCD Monitor Keyboard Drawer

# 1. Table Of Content

1.	Table of Content	P.1
2.	Introduction	P.2
3.	Features	P.2
4.	Package Contents	P.3
5.	Optional Accessories	P.4
6.	Peripheral Products	P.4
7.	Important Safeguards	P.5
8.	Structure Diagram	P.6
9.	Dimension Diagram	
	RKP215	P.7
	RKP217	P.8
	RKP219	P.9
10.	LCD OSD Menu Operation	
	LCD Membrane Diagram	P.10
	Main Menu	P.10
	Sub Menu	P.11-12
11.	Resolution Settings	
	For Windows	P.13
	For Sun Servers	P.14
12.	Technical Specification	P.15

#### 2. Introduction

RKP Series is a combination of keyboard, mouse and monitor into a drawer, with features such as flip-up design, adjustable brackets, built in LCD OSD to provide effective assistant for an administrator to control PC system.

RKP Series provides cost effective for your limited IT budget over using CRT and rack mounting. Also, it will be space saving for your compact environment rack and effective assistant for an administrator to control PC system.

#### 3. Features

- Unique monitor flip up design allows viewing through closed glass door of cabinet
- Three models to choose from 15", 17" or 19" LCD Panel
- Three keyboard selections supporting multiple languages
- Slide rails have two fixed positions to prevent movement of both LCD and keyboard drawer
- Front-access lock for security.
- Build-in slide rail and mounts easily in any 19" cabinet
- Built in On Screen Display controlled by integral membrane switches.
- Lightweight Aluminium construction with black anodize finish
- Supplied with 12V 5A remote power adapter (single power source)

#### **Disclaimer**

This information is subject to change without notice. The producer of this manual accepts no responsibility for damage or claims, resulting from misuse or misinterpretation

### 4. Package Contents

LCD Monitor	1 Piece	
User Manual	1 Piece	
DC Power Adapter	1 Piece	
Power Cord	1 Piece	
Mounting Bracket	1 Pair	
Fasteners	4 Pieces	
Key for front access lock	2 Pieces	
CD-6 3-in-1 KVM cable	1 Piece	

# **Before Unpacking**

It is very important to locate the LCD Keyboard Drawer in a suitable environment.

- The surface for placing and fixing the LCD Keyboard Drawer should be stable and level or mounted into a suitable cabinet.
- Make sure the place has good ventilation, is out of direct sunlight, away from sources of excessive dust, dirt, heat, water, moisture and vibration.
- Convenience for connecting the LCD Keyboard Drawer to the related facilities should be well considers too.

# **Unpacking**

The LCD keyboard drawer comes with the standard parts shown as above. Check and make sure they are included and in good condition. If anything is missing, or damage, contact the supplier immediately.

# 5. Optional Accessories

Model	Description	
SUN-31	SUN / iMac USB to PS/2 adapter	
	Video Input	
	15" - 19" Touch Screen	
	12V / 24V / 48V DC Power Supply	

# 6. Peripheral Products

Model	Description	
CV-401 / CV-801 / CV-1601	4-Port / 8-port / 16-Port PS/2 KVM switch	
CV-1602	16-Port 2-Console PS/2 KVM switch	
CV-S801 / CV-S1601	8-Port /16-port USB KVM switch	
CV-S1602	16-port 2-Console USB KVM switch	
CV-101	CAT.5 PS/2 KVM extender	

# 7. Important Safeguards

Please read all of these instructions carefully before you use the device. Save this manual for future reference.


- Unplug the LCD Keyboard Drawer from the power outlet before cleaning.
- Do not spray liquid cleaners or aerosol directly on the device. Wet a cloth with a neutral detergent (e.g. clean water) and squeeze it tight, then clean the screen slightly with it.
- Do not expose the LCD Keyboard Drawer directly to rain, water, moisture or sunlight.
- Avoid pressure on the LCD screen to prevent permanent damage to the display.
- Do not attempt to service the device yourself. Improper operation may void your warranty. Refer all servicing to qualified service personnel.
- Safe storage environment of the LCD Keyboard Drawer is ranging between −20°C and 60°C. Permanent damage could occur if the LCD Keyboard Drawer is stored outside the safe range.
- Unplug the LCD Keyboard Drawer immediately and call qualified service personnel under the following conditions:
  - 1. If the monitor has been exposed to rain, liquid or water.
  - 2. If the monitor has been dropped or the casing has been damaged.

#### What the warranty does not cover

- 1. Any product, on which the serial number has been defaced, modified or removed.
- 2. Damage, deterioration or malfunction resulting from:
  - a) Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - b) Repair or attempted repair by anyone not authorized by us.
  - c) Any damage of the product due to shipment.
  - d) Removal or installation of the product.
  - e) Causes external to the product, such as electric power fluctuation or failure.
  - f) Use of supplies or parts not meeting our specifications.
  - g) Normal wear and tear.
  - h) Any other causes which does not relate to a product defect.
- 3. Removal, installation, and set-up service charges.


# 8. Structure Diagram

- 1. PS/2 keyboard
- 2. Aluminium front panel
- 3. Class A active matrix TFT LCD panel
- 4. Analog to digital signal converter board
- 5. Rear metal case
- 6. LCD inverter
- 7. LCD membrane
- 8. Ball bearing telescopic slides with stopper
- 9. Adjustable mounting bracket
- 10. Optional KVM switch



# 9. Dimension Diagram


# RKP215 2U 15" LCD Keyboard Drawer



Rev. : 1.0

# 9. Dimension Diagram


# RKP217 2U 17" LCD Keyboard Drawer



Rev. : 1.0


# 9. Dimension Diagram

# RKP219 2U 19" LCD Keyboard Drawer



#### 10. LCD OSD Menu Operation

# **LCD Membrane Diagram**



#### **Main Menu**

#### **Bright / Contrast**

To enter into the Bright, Black level & Contrast sub-menu

#### **Auto Adjust**

- To perform automatic optimisations of all functions
- An "Adjusting" message is displayed during the process

#### Phase / Clock

• To enter into the phase & clock sub menu

#### **H/V Position**

• To enter into the Position sub-menu

#### **MISC**

To enter into the MISC sub-menu

#### Reset

Reset to the default factory settings

#### **LCD OSD Menu Operation** 10.

#### **Bright / Contrast**

# 1. Brightness 💢

- To perform brightness adjustment of the input RGB signal
- Use the Left & Right button to adjust and button



to "Brightness"

#### 2. Contrast 1

- To adjust the contrast level of the input signal
- Use the Left & Right button to adjust and button to "Contrast"



#### Phase / Clock

# 1. Phase

- To adjust input video sampling clock's phase
  - Use the Left & Right button to adjust and button

- 2. Clock
  - To adjust input video sampling clock



Use the Left & Right button to adjust and button

# **H/V Position**

# 1. H.Position

To adjust the horizontal size of the frame



Use the Left & Right button to adjust and button

# 2. V.Position

To adjust the vertical position of the frame



Use the Left & Right button to adjust and button to "V.position".

#### 10. LCD OSD Menu Operation

## **MISC**

#### 1. Information

- The first header row shows the current resolution setup
- The second header row shows the horizontal frequency of the current input signal
- The third header row shows the vertical frequency of the current input signal

#### 2. OSD Timer

To modify the duration of the OSD time-out

#### 3. Color

- a) 5500K
  - Select Colour Temp at 5500K
- b) 6500K
  - Select Colour Temp at 6500K
- c) 9500K
  - Select Colour Temp at 9500K
- d) User
  - Change Colour Temp by manual

#### 4. Language

- To select the language of OSD menu 7 Languages :
  - (1) English
  - (2) Japanese (日本語)
  - (3) Chinese (中文)
  - (4) German
  - (5) Francais
  - (6) Espanol
  - (7) Italiano

# 11. Resolution Settings


# For Microsoft Windows

Step 1 – Press right click on the desktop


Step 2 – Choose "Properties"



Step 3 - Change the "Screen Resolution"



Step 4 - Change the "Screen refresh rate"



#### 11. Resolution Settings

#### **For SUN Servers**

- Resolution configuration procedures should be run by qualified SUN server administrator
- Sun Servers are using resolution at 1152 x 900 x 76Hz.
- Supported resolution mode for 15" LCD:
- 1024 x 768 x 70/75Hz
- Supported resolution mode for 17" LCD:
- 1280 x 1024 x 75Hz
- You need to change the Sun Server resolution before you connect to LCD Display.
- Please do the following procedures to change the resolution settings:
  - 1. As root:

You may find the following comment "/user/sbin/m64config".

2. To view current resolution:

Type "/user/sbin/m64config – prconf".

3. To change to 1024x768 @ 70MHz:

Type "/user/sbin/m64config – res 1024x768x70 now".

- 4. The screen will be rubbish.
- 5. Then type "pkill Xsun".

And Type "pkill Xsession" to restart the Xsession.

**Note:** Remember to RESTART the server after these processes.

- Under Common Desktop Environment (CDE).
- To change the OpenBoot resolution, you can type the following command in OK prompt.
  - 1. In OK prompt, type "setenv output-device screen:r1024x768x70".
  - 2. Type "printenv" to confirm the resolution has been changed to 1024x768x70Hz.
  - 3. Then type, "reset" to restart the system.

**Note**: Remember to RESTART the server after these processes

# 12. Technical Specification

Item	Description			
LCD Screen Manufacturer	SAMSUNG			
LCD Origin				
Panel	15" TFT	17" TFT	19" TFT	
Resolution	1,024 x 768	1,280 x 1,024	1,280 x 1,024	
Brightness	300 cd/m <sup>2</sup>	350 cd/m <sup>2</sup>	500 cd/m <sup>2</sup>	
Color	16.2 Million	16.2 Million	16.7 Million	
Contrast Ratio	450:1	350:1	500:1	
Viewing Angle	140° x 125°	140° x 120°	170° x 170°	
Display Area	304 x 228 mm	337 x 270 mm	376 x 301 mm	
Pixel Pitch	0.297 mm	0.264 mm	0.294 mm	
Response Time (Tr)	5ms		15ms	
Response Time (Tf)	20ms		10ms	
Back Light	4 x Cold Cathode Fluorescer		nt Tube	
Horizontal Sync.	48.4 kHz	64 ~ 80 kHz	64 kHz	
Vertical Sync.	65 MHz	60 ~ 75 Hz	60 Hz	
Input Signal	Analog RGB 0.7Vp-p			
Power Management	VESA DPMS			
	Brightness, Contract, Colour, Clock			
OSD Control	H.Position, V.Position, Phase, Scaling			
	Auto Config., Input Select, Multi-Window			
	Clear EEPROM, OSD adjust			
Power Input	12V DC Adapter			
Video Input	15-pin D-Sub Connector			
Dimension	RKP215 / 217 / 219 : 44.2W x 8.8H x 60D cm			
Weight RKP215: 12kg / 217: 13kg / 219: 15kg				