

Wire two ADC-VDB770s to a mechanical chime

Two ADC-VDB770s can be wired to a single mechanical chime. Digital chimes do not support this wiring configuration.

For more information about enrolling the ADC-VDB770s, see [Alarm.com Video Doorbell \(ADC-VDB770\) - Installation Guide](#).

Wire two ADC-VDB770s to a mechanical chime

Wiring

Doorbell camera 1

1. On the power module, attach the white wires interchangeably to the *FRONT* and *TRANS* terminals on the chime.
2. Attach the gray wires interchangeably to the transformer and the ADC-VDB770.
3. On the ADC-VDB770, attach the remaining wire to the transformer.

Doorbell camera 2

1. On the power module, attach the white wires interchangeably to the *REAR* and *TRANS* terminals on the chime.
2. Attach the gray wires interchangeably to the transformer and the ADC-VDB770.
3. On the ADC-VDB770, attach the remaining wire to the transformer.

Diagram

