Emergency Call Button with Interlogix Transmitter

ADC-EPB-BC2.1-GE

Stationary Emergency Button 319.5 MHz

Interlogix & Qolsys Compatible

Specifications

|	
Enclosure	4.75 in. x 2.25 in. (Diameter x Depth) Black, ABS plastic base with slip-resistant feet and 3 x AAA battery housing for optional audible message on button press Red, ABS plastic, spring-loaded push button
Electronic Signaling	Battery-powered filter circuit with integrated 345 MHz (crystal-controlled) Interlogix-compatible transmitter with 64 minute supervisory interval
Sensing Interface	Filtered, normally open (i.e. when not pressed), momentary contact switch
Battery Life	Replaceable 3x AAA battery: 2+ years

Programming

1. Use the Alarm.com AirFX "Add a Sensor" interface or the panel interface to add the button to the account. Set the "New Sensor Information" as shown in the chart.

- For enrolling the device at the panel, the sensor can be tampered by pressing the button within the first two seconds that the On/Off switch is set to the "On" position.
  - Please note that group 4 should be used if the button is used to signal an emergency.
  - Group 40 or group 27 can be used if the button is not being used to signal an emergency.
2. After the sensor is added to the system, change the sensor type to "Push Button."
  - From the *Equipment* page of the Dealer Website click **Change** to the right of the sensor's name.
  - Select the "Change Sensor Type" action, and update the new sensor type to "Push Button."

Sensor ID	(Select an unused ID)
Group	4 (Emergency) or 40 (Non-Emergency)
Sensor Name	(Any)
DL Code	(On the bottom of the sensor)

Installation

Locate the sensor within 100 feet of the base station. Ensure that the On/Off switch on the base of the button is set to the "On" position. The sensor can be mounted using the included mounting plate and mounting hardware or simply place the sensor on a flat surface in a visible location.

Tamper

Note that the device may signal a tamper if the button is pressed within the first two seconds after the on/off switch is set to the "On" position.

Use

Press and hold the switch for one second.