

## Where does an ADC-W110 appear on an account?

The ADC-W110 automatically enrolls itself under the video device it is connected to. Users can view the ADC-W110's details, and troubleshoot remotely using the Partner Portal. For more information about the ADC-W110 enrollment process, see <u>Automatic account association</u> in the installation guide.

## To view the ADC-W110 using the Partner Portal:

- 1. Log into the Partner Portal.
- 2. Find the account.
- 3. Click Equipment.
- 4. Click Video Devices.
- 5. Using the *Video Device* dropdown menu, select the video device connected to the ADC-W110 (e.g., if the ADC-W110 is connected to a video device named Front Door Cam, select Front Door Cam).
- 6. Scroll to Wi-Fi Bridge: ADC-W110.



